


# AC Servo Drives \[ \sumset - V Series \] USER'S MANUAL Setup Linear Motor

SGDV SERVOPACK
SGLGW/SGLFW/SGLTW/SGLC/SGT Linear Servomotors



Overview of Setup

Installation

Wiring and Connection

Safety Function

Trial Operation (Checking Linear Servomotor Operation)

5



# About this Manual

This manual describes procedures required for installation, wiring, and connecting  $\Sigma$ -V Series servo drives, including a JOG operation for linear servomotors not connected to machinery.

Be sure to refer to this manual and perform setup operations correctly.

Keep this manual in a location where it can be accessed for reference whenever required.

#### ■ Description of Technical Terms

The following table shows the meanings of terms used in this manual.

| Term                              | Meaning   |  |  |  |
|-----------------------------------|---|--|--|--|
| Cursor                            | Input position indicated by Digital Operator  |  |  |  |
| Linear Servomotor                 | $\Sigma\text{-V}$ Series SGLGW, SGLFW, SGLTW, or SGLC linear servomotor, or SGT linear slider   |  |  |  |
| SERVOPACK                         | Σ-V Series SGDV SERVOPACK   |  |  |  |
| Servo Drive                       | A set including a linear servomotor and SERVOPACK (i.e., a servo amplifier)   |  |  |  |
| Servo System                      | A servo control system that includes the combination of a servo drive with a host controller and peripheral devices                                 |  |  |  |
| Analog Pulse Model                | Analog voltage and pulse-train reference used for SERVOPACK interface.  |  |  |  |
| M-II Model                        | MECHATROLINK-II communications reference used for SERVOPACK interface.  |  |  |  |
| M-III Model                       | MECHATROLINK-III communications reference used for SERVOPACK interface.   |  |  |  |
| Command Option<br>Attachable Type | SERVOPACK for which a command option module can be installed.   |  |  |  |
| Servo ON                          | Power to motor ON   |  |  |  |
| Servo OFF                         | Power to motor OFF  |  |  |  |
| Base Block (BB)                   | Power supply to motor is turned OFF by shutting off the base current to the power transistor in the current amplifier.                              |  |  |  |
| Linear Scale Connection<br>Cables | A set of cables including a cable for connecting serial converter unit, a cable for connecting linear scale, and a cable for connecting hall sensor |  |  |  |

# ■ IMPORTANT Explanations

The following icon is displayed for explanations requiring special attention.



Indicates important information that should be memorized, as well as
precautions, such as alarm displays, that do not involve potential damage
to equipment.

#### ■ Notation Used in this Manual

In this manual, the names of reverse signals (ones that are valid when low) are written with a forward slash (/) before the signal name, as shown in the following example:

#### Example

 $\overline{S-ON} = /S-ON$ 

# ■ Manuals Related to the ∑-V Series

Refer to the following manuals as required.

| Name   | Selecting<br>Models<br>and<br>Peripheral<br>Devices | Ratings<br>and<br>Specifi-<br>cations | System<br>Design | Panels<br>and<br>Wiring | Trial<br>Operation | Trial<br>Operation<br>and<br>Servo<br>Adjustment | Maintenance<br>and<br>Inspection |
|--|---|---------------------------------------|------------------|-------------------------|--------------------|--|----------------------------------|
| Σ-V Series<br>Product Catalog<br>(KAEP S800000 42)   | <b>√</b>  | <b>√</b>                              |                  |                         |                    |  |                                  |
| Σ-V Series User's Manual Design and Maintenance Linear Motor/Analog Voltage and Pulse Train Reference (SIEP S800000 47)  |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | <b>✓</b> *                       |
| S-V Series User's Manual Design and Maintenance Linear Motor/ MECHATROLINK-II Communications Reference (SIEP S800000 48) |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | √*                               |
| Σ-V Series<br>User's Manual<br>MECHATROLINK-II<br>Command<br>(SIEP S800000 54)   |   |                                       | <b>√</b>         |                         | <b>~</b>           | <b>√</b>   |                                  |

(cont'd)

|   |   |                                       |                  |                         |                    |  | (cont'd)                         |
|---|---|---------------------------------------|------------------|-------------------------|--------------------|--|----------------------------------|
| Name  | Selecting<br>Models<br>and<br>Peripheral<br>Devices | Ratings<br>and<br>Specifi-<br>cations | System<br>Design | Panels<br>and<br>Wiring | Trial<br>Operation | Trial<br>Operation<br>and<br>Servo<br>Adjustment | Maintenance<br>and<br>Inspection |
| Σ-V Series<br>User's Manual<br>Operation of Digital<br>Operator<br>(SIEP S800000 55)  |   |                                       |                  |                         | <b>✓</b>           | <b>√</b>   | <b>✓</b>                         |
| Σ-V Series<br>User's Manual<br>MECHATROLINK-III<br>Command<br>(SIEP S800000 63)   |   |                                       | <b>~</b>         |                         | <b>✓</b>           | <b>√</b>   |                                  |
| Σ-V Series User's Manual Design and Maintenance Linear Motor/ MECHATROLINK-III Communications Reference (SIEP S800000 65)           |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | <b>√</b> *                       |
| Σ-V Series<br>User's Manual<br>Design and<br>Maintenance<br>Linear Motor/<br>Command Option<br>Attachable Type<br>(SIEP S800000 66) |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | <b>√</b>                         |
| Σ-V Series<br>User's Manual<br>Indexer Module<br>(SIEP C720829 02)  |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | <b>√</b> *                       |
| Σ-V Series<br>User's Manual<br>EtherCAT (CoE)<br>Network Module<br>(SIEP C720829 04)  |   | <b>√</b>                              | <b>√</b>         | <b>√</b>                |                    | <b>√</b>   | ✓ *                              |
| AC SERVOMOTOR<br>Safety Precautions<br>(TOBP C230200 00)  |   |                                       |                  | ✓                       |                    |  | <b>√</b>                         |
| Σ-V Series<br>AC SERVOPACK<br>SGDV Safety<br>Precautions<br>(TOBP C710800 10)   | <b>✓</b>  |                                       |                  | <b>✓</b>                |                    |  | <b>~</b>                         |
| Σ-V Series<br>Option Module<br>Safety Precautions<br>(TOBP C720829 00)  | <b>✓</b>  |                                       |                  | <b>√</b>                |                    |  | <b>√</b>                         |

(cont'd)

|  |   |                                       |                  |                         |                    |  | (cont u)                         |
|--|---|---------------------------------------|------------------|-------------------------|--------------------|--|----------------------------------|
| Name   | Selecting<br>Models<br>and<br>Peripheral<br>Devices | Ratings<br>and<br>Specifi-<br>cations | System<br>Design | Panels<br>and<br>Wiring | Trial<br>Operation | Trial<br>Operation<br>and<br>Servo<br>Adjustment | Maintenance<br>and<br>Inspection |
| Σ-V Series<br>Command Option<br>Module<br>Installation Guide<br>(TOBP C720829 01)  | <b>✓</b>  |                                       |                  | <b>~</b>                |                    |  | <b>√</b>                         |
| Σ-V Series<br>Indexer Module<br>Installation Guide<br>(TOBP C720829 02)            | <b>~</b>  |                                       |                  | <b>√</b>                |                    |  | <b>√</b>                         |
| Σ-V Series<br>Feedback Option<br>Module<br>Installation Guide<br>(TOBP C720829 03) | <b>✓</b>  |                                       |                  | <b>~</b>                |                    |  | <b>√</b>                         |
| Σ Series Digital Operator Safety Precautions (TOBP C730800 00)                     |   |                                       |                  |                         |                    |  | <b>√</b>                         |

<sup>\*</sup> Refer to these manuals for troubleshooting of problems which may occur during setup. (Troubleshooting which is common for command option modules is described in £V Series User's Manual Design and Maintenance Linear Motor/Command Option Attachable Type (SIEP S800000 66).

#### ■ Safety Information

The following conventions are used to indicate precautions in this manual. Failure to heed precautions provided in this manual can result in serious or possibly even fatal injury or damage to the products or to related equipment and systems.

**⚠** WARNING

Indicates precautions that, if not heeded, could possibly result in loss of life or serious injury.

Indicates precautions that, if not heeded, could result in relatively serious or minor injury, damage to the product, or faulty operation.

In some situations, the precautions indicated could have serious consequences if not heeded.

○ PROHIBITED

Indicates prohibited actions that must not be performed. For example, this symbol would be used to indicate that fire is prohibited as follows:



Indicates compulsory actions that must be performed. For example, this symbol would be used as follows to

indicate that grounding is compulsory:

# Safety Precautions

These safety precautions are very important. Read them before performing any procedures such as checking products on delivery, storage and transportation, installation, wiring, operation and inspection, or disposal. Be sure to always observe these precautions thoroughly.

#### WARNING

- If you have a pacemaker or any other electronic medical device, do not go near the magnetic way of the linear servomotor.
   Failure to observe this warning may result in the malfunction of the medical device.
- Be sure to use nonmagnetic tools when installing or working close to the linear servomotor.
   (Example: a beryllium-copper alloy hexagonal wrench set, made by NGK Insulators, Ltd.)
- Never touch the linear servomotor or machinery during operation.
   Failure to observe this warning may result in injury.
- Before starting operation with a machine connected, make sure that an
  emergency stop can be applied at any time.
   Failure to observe this warning may result in injury or damage to the product.
- Before wiring, install the SERVOPACK and the linear servomotor.
   Failure to observe this warning may result in electric shock.
- Never touch the inside of the SERVOPACKs.
   Failure to observe this warning may result in electric shock.
- Do not remove the cover of the power supply terminal while the power is ON.
  - Failure to observe this warning may result in electric shock.
- After the power is turned OFF or after a voltage resistance test, do not touch terminals while the charge indicator is ON.
   Residual voltage may cause electric shock.
- Follow the procedures and instructions provided in this manual for trial operation.
   Failure to do so may result not only in faulty operation and damage to equipment, but also in personal injury.
- Do not remove the front cover, cables, connectors, or optional items from the upper front of the SERVOPACK while the power is ON.
   Failure to observe this warning may result in electric shock.
- Do not damage, press, exert excessive force on, or place heavy objects on the cables.
   Failure to observe this warning may result in electric shock, stopping operation of the product, or fire.
- Do not modify the product. Failure to observe this warning may result in injury, fire, or damage to the product.

#### WARNING

- Provide an appropriate braking device on the machine side to ensure safety.
  - Failure to observe this warning may result in injury.
- Do not come close to the machine immediately after resetting a momentary power loss. The machine may restart unexpectedly. Take appropriate measures to ensure safety against an unexpected restart.
   Failure to observe this warning may result in injury.



• Connect the ground terminal according to local electrical codes (100  $\Omega$  or less for a SERVOPACK with a 100, 200 V power supply. 10  $\Omega$  or less for a SERVOPACK with a 400 V power supply.) Improper grounding may result in electric shock or fire.



- Installation, disassembly, or repair must be performed only by authorized personnel.
   Failure to observe this warning may result in electric shock or injury.
- The person who designs a system using the safety function (Hard Wire Base Block function) must have full knowledge of the related safety standards and full understanding of the instructions in Σ-V Series User's Manual Design and Maintenance (SIEP S800000 47/48/65/66).
   Failure to observe this warning may result in injury or damage to the product.

#### ■ Storage and Transportation

#### CAUTION

- Be sure to store the magnetic way in the package that was used for delivery.
- Do not store or install the product in the following locations.
   Failure to observe this caution may result in fire, electric shock, or damage to the product.
  - · Locations subject to direct sunlight
  - Locations subject to temperatures outside the range specified in the storage/ installation temperature conditions
  - Locations subject to humidity outside the range specified in the storage/installation humidity conditions
  - Locations subject to condensation as the result of extreme changes in temperature
  - · Locations subject to corrosive or flammable gases
  - · Locations subject to dust, salts, or iron dust
  - Locations subject to exposure to water, oil, or chemicals
  - · Locations subject to shock or vibration
- Do not carry the linear servomotor by its cables. Failure to observe this caution may result in injury or malfunction.
- Do not place any load exceeding the limit specified on the packing box.
   Failure to observe this caution may result in injury or malfunction.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, pallets, or plywood, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

#### ■ Installation

# **↑** CAUTION


- When unpacking and installing magnetic way, check that no metal fragments or magnetized objects near the magnetic because they may be affected by the magnetic attraction of the magnetic way.
   Failure to observe this caution may result in injury or damage to the magnetic way's magnets.
- Do not use the magnetic way near metal or other magnetized objects. Failure to observe this caution may result in injury.

#### ■ Installation (cont'd)

#### **↑** CAUTION

- Do not place clocks, magnetic cards, floppy disks, or measuring instruments close to the magnetic way.
   Failure to observe this caution may result in malfunction or damage to these items by the magnetic force.
- Securely mount the linear servomotor onto the machine.

  If the linear servomotor is not mounted securely, it may loosen during operation.
- Do not carry the magnetic way by its magnet protection cover.
   Failure to observe this caution may result in injury by the cover's edge or the shape of the cover may become distorted.



- When removing the dummy plate for reducing magnetic force used for the SGLFW magnetic way, pay attention to the magnetic attraction of the magnetic way. Do not place the removed plate close to the magnetic way.
   Failure to observe this caution may result in injury or damage to the magnetic way's magnets or the magnet protection cover.
- Install SERVOPACKs, linear servomotors, and regenerative resistors on nonflammable objects.
   Installation directly onto or near flammable objects may result in fire.
- Never use the product in an environment subject to water, corrosive gases, inflammable gases, or combustibles.
   Failure to observe this caution may result in electric shock or fire.
- Do not step on or place a heavy object on the product.
   Failure to observe this caution may result in injury or malfunction.
- Do not cover the inlet or outlet ports and prevent any foreign objects from entering the product.
  - Failure to observe this caution may cause internal elements to deteriorate resulting in malfunction or fire.
- Be sure to install the product in the correct direction.
   Failure to observe this caution may result in malfunction.
- Provide the specified clearances between the SERVOPACK and the control panel or with other devices.
   Failure to observe this caution may result in fire or malfunction.
- Do not apply any strong impact.
  Failure to observe this caution may result in malfunction.

#### ■ Wiring

## **A CAUTION**

- Be sure to wire correctly and securely.
   Failure to observe this caution may result in motor overrun, injury, or malfunction.
- Securely tighten the cable connector screws and securing mechanism.
   If the connector screws and securing mechanism are not secure, they may loosen during operation.
- Use cables with a radius, heat resistance, and flexibility suitable for the system.
- If the SERVOPACK malfunctions, turn OFF the main circuit's power supply of the SERVOPACK.

The continuous flow of a large current may cause fire.

- Use a noise filter to minimize the effects of electromagnetic damage.
   Failure to observe this caution may result in electromagnetic damage to electronic devices used near the SERVOPACK.
- Do not connect a commercial power supply to the U, V, or W terminals for the linear servomotor connection.
   Failure to observe this caution may result in injury or fire.
- Securely connect the main circuit power supply terminals and linear servomotor connection terminals.
   Failure to observe this caution may result in fire.
- Do not bundle or run the main circuit cables together with the I/O signal cables or the linear scale connection cables in the same duct. Keep them separated by at least 30 cm.
   Failure to do so may result in malfunction.
- Use shielded twisted-pair wires or multi-core shielded twisted-pair wires for I/O signal cables and the linear scale connection cables.
- The maximum cable length is 3 m for the I/O signals, 20 m for the linear servomotor main circuit, 20 m for the serial converter unit, 15 m for the linear scale, 15 m for the hall sensor, and 10 m for control power supply cables for the SERVOPACK with a 400-V power supply (+24 V, 0 V).
- Do not touch the power terminals while the charge indicator is ON after turning power OFF because high voltage may still remain in the SERVO-PACK.

Make sure the charge indicator is off first before starting wiring and inspection.

- Be sure to observe the following precautions when wiring the SERVO-PACK main circuit terminals has been completed.
  - Do not turn ON the power to the SERVOPACK until all wiring including main circuit terminals has been completed.
  - Remove detachable main circuit terminals from the SERVOPACK prior to wiring.
  - Insert only one main circuit cable per opening in the main circuit terminals.
  - Make sure that no part of the core wire comes into contact with (i.e., short-circuit) adjacent wires.
- Do not connect the SERVOPACK for 200 V directly to a voltage of 400 V. The SERVOPACK will be destroyed.
- Always use the specified power supply voltage:
   Failure to observe this caution may result in fire or product failure.

#### ■ Wiring (cont'd)

#### **⚠** CAUTION

- Make sure that the polarity is correct.
   Incorrect polarity may cause ruptures or damage.
- Take appropriate measures to ensure that the input power supply is supplied within the specified voltage fluctuation range. Be particularly careful in places where the power supply is unstable.
   An incorrect power supply may result in damage to the product.
- Install external breakers or other safety devices against short-circuiting in external wiring.

Failure to observe this caution may result in fire.

 Take appropriate and sufficient countermeasures for each form of potential interference when installing systems in the following locations.
 Failure to observe this caution may result in damage to the product.

• Locations subject to static electricity or other forms of noise

- Locations subject to strong electromagnetic fields and magnetic fields
- Locations subject to possible exposure to radioactivity
- Locations close to power supplies

Failure to observe this caution may result in damage to the product.

- · Wiring or inspection must be performed by a technical expert.
- Use a 24 VDC power supply with double insulation or reinforced insulation
- Failures caused by incorrect wiring or wrong voltage application in the brake circuit may damage the equipment or cause an accident resulting in death or injury. Follow the procedures and instructions for wiring and trial operation precisely as described in this manual.
- Leakage current may increase depending on the type of noise filter and the grounding conditions.
   When using a detector or a breaker for leakage current, select the appropriate one by considering the type of noise filter and the ground conditions.
   For details, contact the manufacturer of the noise filter.
- Incorrect wiring or incorrect voltage application to the output circuit may cause short-circuit.
   The above failures will prevent the holding brake from working, which may dam-

age the machine or cause an accident resulting in death or injury.

Inverting the polarity of the brake signal (/BK), i.e. positive logic, will prevent the holding brake from working in case of its signal line disconnection.
 If this setting is absolutely necessary, check the operation and confirm that there are no safety problems.

#### Operation

# **∧** CAUTION

- Do not stand within the machine's range of motion during operation. Failure to observe this caution may result in injury.
- Always use the linear servomotor and SERVOPACK in one of the specified combinations.

Failure to observe this caution may result in fire or malfunction.

#### ■ Operation (cont'd)

# **A CAUTION**

- If the SERVOPACK, the absolute linear scale, or the linear servomotor is replaced, the polarity detection function must be executed again.
   Failure to observe this caution may result in the linear servomotor moving in an unpredictable manner.
- Before operation, install a limit switch or stopper on the end of the slider to prevent unexpected movement.
   Failure to observe this caution may result in injury.
- During trial operation, confirm that the holding brake works correctly. Furthermore, secure system safety against problems such as signal line disconnection.
- Before starting operation with a machine connected, change the settings to match the parameters of the machine.
   Starting operation without matching the proper settings may cause the machine to run out of control or malfunction.
- · Do not frequently turn power ON and OFF.
  - Frequently turning power ON and OFF causes elements inside the SERVOPACK to deteriorate. Do not use the servo drive with an application that requires frequently turning power ON and OFF.
  - After the actual operation starts, the allowable interval for turning power ON and OFF is one hour or longer.
- When carrying out JOG operation (Fn002), origin search (Fn003), or EasyFFT (Fn206), forcing movable machine parts to stop does not work for forward overtravel or reverse overtravel. Take necessary precautions.
   Failure to observe this caution may result in damage to the equipment.
- When using the linear servomotor for a vertical axis, install safety devices
  to prevent workpieces from falling due to alarms or overtravels. Set the linear servomotor so that it will stop in the zero clamp state when overtravel
  occurs
  - Failure to observe this caution may cause workpieces to fall due to overtravel.
- When not using turning-less function, set the correct mass ratio (Pn103).
   Setting an incorrect mass ratio may cause machine vibration.
- Do not touch the SERVOPACK heatsinks, regenerative resistor, or linear servomotor while power is ON or soon after the power is turned OFF.
   Failure to observe this caution may result in burns due to high temperatures.
- Do not make any extreme adjustments or changes in the settings of parameters.
  - Failure to observe this caution may result in injury or damage to the product due to unstable operation.
- If an alarm occurs, shut down the main circuit power supply.
   Failure to observe this caution may result in fire due to regenerative resistor overheating caused by regenerative transistor failure.
- When an alarm occurs, remove the cause, reset the alarm after confirming safety, and then resume operation.
   Failure to observe this caution may result in damage to the product, fire, or injury.
- An alarm or warning may be generated if communications are executed with the host controller during operation using SigmaWin+ or the digital operator.

If an alarm or warning is generated, the process currently being executed may be aborted and the system may stop

#### ■ Maintenance and Inspection

#### **⚠** CAUTION

- Do not disassemble the linear servomotor. Failure to observe this caution may result in electric shock or injury.
- · Do not attempt to change wiring while the power is ON. Failure to observe this caution may result in electric shock or injury.
- · When replacing the SERVOPACK, resume operation only after copying the previous SERVOPACK parameters to the new SERVOPACK. Failure to observe this caution may result in damage to the product.
- Be sure to eliminate static electricity before operating buttons and switches inside the front cover. Failure to observe this caution may result in damage to the product.

#### ■ Disposal

# **∧** CAUTION

When disposing of the products, treat them as ordinary industrial waste.

#### General Precautions

# Observe the following general precautions to ensure safe application.

- · The products shown in illustrations in this manual are sometimes shown without covers or protective guards. Always replace the cover or protective guard as specified first, and then operate the products in accordance with the manual.
- The drawings presented in this manual are typical examples and may not match the
- product you received.

  If the manual must be ordered due to loss or damage, inform your nearest Yaskawa representative or one of the offices listed on the back of this manual.

# Warranty

#### (1) Details of Warranty

#### ■ Warranty Period

The warranty period for a product that was purchased (hereinafter called "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

#### ■ Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the warranty period above. This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- 2. Causes not attributable to the delivered product itself
- 3. Modifications or repairs not performed by Yaskawa
- Abuse of the delivered product in a manner in which it was not originally intended
- 5. Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from Yaskawa
- Events for which Yaskawa is not responsible, such as natural or human-made disasters

# (2) Limitations of Liability

- 1. Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- 2. Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- 3. The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- 4. Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

#### (3) Suitability for Use

- 1. It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- 3. Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
  - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
  - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
  - Systems, machines, and equipment that may present a risk to life or property
  - Systems that require a high degree of reliability, such as systems that supply
    gas, water, or electricity, or systems that operate continuously 24 hours a day
  - Other systems that require a similar high degree of safety
- 4. Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- 6. Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

# (4) Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

# Applicable Standards

■ North American Safety Standards (UL)



| Model     |      | UL* Standards<br>(UL File No.) |  |
|-----------|------|--------------------------------|--|
| SERVOPACK | SGDV | UL508C (E147823)               |  |

<sup>\*</sup> Underwriters Laboratories Inc.

## ■ European Standards



|           | Model  | Low Voltage            | EMC Directive                              |                          | Safety                        |
|-----------|--------|------------------------|--|--------------------------|-------------------------------|
|           | Wiodei | Directive              | EMI  | EMS                      | Standards                     |
| SERVOPACK | SGDV   | EN50178<br>EN61800-5-1 | EN55011/A2<br>group 1 class A<br>EN61800-3 | EN61800-3<br>EN61000-6-2 | EN954-1<br>IEC61508-1<br>to 4 |

Note: Because SERVOPACKs and linear servomotors are built into machines, certification is required after installation in the user's product.

# Contents

|   | About this Manual Safety Precautions Warranty Applicable Standards   | viii<br>xvi<br>kviii   |
|---|--|--|
| 1 | Overview of Setup  | 1-1  |
| 2 | Installation   | 2-1  |
|   | 2.1 Installation Environment and Applicable Standards 2.1.1 Linear Servomotor Installation Environment 2.1.2 SERVOPACK Installation Environment 2.1.3 Installation Conditions for Applicable Standards 2.2 Linear Servomotor Installation 2.2.1 SGLGW and SGLGM Linear Servomotors (Coreless Type) 2.2.2 SGLFW and SGLFM Linear Servomotors (F-type Iron Core) 2.2.3 SGLTW and SGLTM Linear Servomotors (T-type Iron Core) 2.2.4 SGLC Linear Servomotors (Cylinder Type) 2.3 Linear Scale Installation and Adjustment 2.3.1 Installation Conditions 2.3.2 Installation 2.3.3 Adjustment 2.4 SERVOPACK Installation 2.4.1 Orientation 2.4.2 Installation Standards 2.5 EMC Installation Conditions 2.5.1 SGDV-□□□□□5□ (Analog Pulse Model) 2.5.2 SGDV-□□□□□5□ (M-III Model) 2.5.3 SGDV-□□□□□5□ (M-III Model) 2.5.4 SGDV-□□□□□5□ (M-III Model) 2.5.5 Other Precautions | 2-2<br>2-3<br>2-4<br>2-5<br>2-5<br>2-8<br>. 2-14<br>. 2-21<br>. 2-27<br>. 2-30<br>. 2-32<br>. 2-33<br>. 2-35<br>. 2-37<br>. 2-45<br>. 2-53<br>. 2-61 |
| 3 | Wiring and Connection  |  |
|   | 3.1 Precautions for Wiring  3.2 System Configuration Diagram  3.2.1 Connecting to SGDV-□□□□□05□ SERVOPACK (Analog Pulse Model)  3.2.2 Connecting to SGDV-□□□□□15□ SERVOPACK (M-II Model)  3.2.3 Connecting to SGDV-□□□□□25□ SERVOPACK (M-III Model)  3.2.4 Connecting to SGDV-□□□□□E5A SERVOPACK  (Command Option Attachable Type)  3.3 Main Circuit Wiring  3.3.1 Main Circuit Terminals  3.3.2 When Using a Standard Power Supply Input  (Single-phase 100 V, Three-phase 200 V, or Three-phase 400 V)   | 3-4<br>3-8<br>. 3-12<br>. 3-16<br>. 3-20<br>. 3-20   |
|   | 3.3.3 When Using the SERVOPACK with a Single-phase 200 V Power Input   | 3-27   |

| 3-36<br>3-38<br>3-38<br>3-41<br>3-42<br>3-42  |
|---|
| 3-43  |
|   |
| 4-2<br>4-3<br>4-4<br>4-5  |
| 5-1   |
| 5-2<br>5-3<br>5-4<br>5-9<br>5-9<br>5-11<br>5-12<br>5-15<br>5-16<br>5-21<br>5-23<br>5-24<br>5-27<br>5-29 |
|   |

# **Revision History**

# Overview of Setup

This chapter describes how to set up the  $\Sigma$ -V series of servo drives.

This chapter describes the flow of the setup procedure from installation until a JOG operation. A panel operator, a digital operator, and SigmaWin+, which is an engineering tool that can be used with a PC, are available to set up a servo drive.

The panel operator is included with the SERVOPACK of analog pulse models, and the digital operator and SigmaWin+ are sold separately.

# **A CAUTION**

 An alarm or warning may be generated if communications are executed with the host controller during operation using SigmaWin+ or the digital operator.
 If an alarm or warning is generated, the process currently being executed may be aborted and the system may stop.



Be sure to read 5.2 Inspection and Checking before Trial Operation.

| Ste |  |  |  |
|-----|--|--|--|
| p   | Item   | Description  | Reference  |
| 1   | Installation and mounting  | Install the linear servomotor, linear scale, and SERVO-<br>PACK according to the installation conditions.  | Chapter 2 Installation   |
| 4   | •  |  |  |
| 2   | Wiring and connections   | Wire and connect the SERVOPACK main circuit, regenerative resistor, linear servomotor, and linear scale.   | Chapter 3 Wiring and Connection  |
| 4   | ,  |  |  |
| 3   | Check points<br>before trial<br>operation  | For a safe and correct trial operation, inspect and check the following items before trial operation.  Linear servomotor  SERVOPACK  Wiring for main circuit power supply, linear servomotor, and linear scale             | 5.2 Inspection and Checking before Trial Operation (1) Linear Servomotors (2) SERVOPACKs (3) Checking the Main Circuit Power Supply, Linear Servomotor, and Linear Scale Wirings                                   |
| 4   | ,  |  |  |
| 4   | SERVOPACK<br>'s parameter<br>setting   | Set the following parameters of the SERVOPACK.  Linear scale pitch (Pn282)  Hall sensor selection (Pn080.0)  Motor phase selection (Pn080.1)  Overtravel signal allocation (Pn50A.3, Pn50B.0)  Force limits (Pn483, Pn484) | 5.3 Setting the SERVOPACK Parameters 5.3.1 Setting and Checking the Linear Scale Pitch 5.3.2 Hall Sensor Selection 5.3.3 Motor Phase Selection 5.3.4 Setting the Overtravel Signals 5.3.5 Setting the Force Limits |
| _   | ,  |  |  |
| 5   | Origin setting When using an absolute linear scale manufactured by Mitutoyo Corporation, execute the origin setting (Fn020). |  | 5.4 Execution of Origin Setting (Fn020)  |
| 4   | ,  |  |  |
| 6   | Polarity detection   | Execute the polarity detection.  | 5.5 Polarity Detection   |
| 1   | <b>,</b>   |  |  |
| 7   | JOG<br>operation   | Perform a JOG operation for the linear servomotor using:  • Panel operator (for analog pulse models only),  • Digital operator, or  • SigmaWin+  | 5.6 JOG Operation 5.6.1 JOG Operation Using a Panel Operator 5.6.2 JOG Operation Using a Digital Operator 5.6.3 JOG Operation Using SigmaWin+  |

# Installation

This chapter describes how to install the linear servomotor and the SERVO-PACK.

| Installation Environment and Applicable Standards   | 2-2                  |
|---|----------------------|
| 2.1.3 Installation Conditions for Applicable Standards  |                      |
| <ul> <li>2.2 Linear Servomotor Installation</li></ul>   | 2-5<br>2-8<br>2-14   |
| 2.3 Linear Scale Installation and Adjustment 2.3.1 Installation Conditions 2.3.2 Installation 2.3.3 Adjustment  | 2-27                 |
| 2.4 SERVOPACK Installation 2.4.1 Orientation 2.4.2 Installation Standards   | 2-33                 |
| 2.5 EMC Installation Conditions  2.5.1 SGDV-□□□□05□ (Analog Pulse Model)  2.5.2 SGDV-□□□□15□ (M-II Model)  2.5.3 SGDV-□□□□25□ (M-III Model)  2.5.4 SGDV-□□□□□E5A (Command Option Attachable Type) | 2-37<br>2-45<br>2-53 |
| 2.5.5 Other Precautions   | 2-61                 |

#### 2.1.1 Linear Servomotor Installation Environment

# **2.1** Installation Environment and Applicable Standards

The installation environment and the applicable standards for linear servomotors and SERVOPACKs are described in this section.

#### **2.1.1** Linear Servomotor Installation Environment


■ Ambient temperature: 0°C to 40°C

■ Ambient humidity: 20% to 80% RH or less (with no condensation)

■ Altitude: 1, 000 m or less

■ Vibration resistance: The linear servomotor will withstand the following vibration acceleration in three directions: vertical, side to side, and front to back.

| Servomoto               | or Model       | Vibration Acceleration at Flange |                       |  |
|-------------------------|----------------|----------------------------------|-----------------------|--|
| SGLGW<br>SGLFW<br>SGLTW |                | three directions                 | 49 m/s <sup>2</sup>   |  |
|                         | Moving<br>Coil | three directions                 | 24.5 m/s <sup>2</sup> |  |
| SGLC                    | Magnetic       | axis direction                   | 24.5 m/s <sup>2</sup> |  |
|                         | Way            | vertical, hori-<br>zontal        | 4.9 m/s <sup>2</sup>  |  |



■ Impact Resistance: The linear servomotor will with stand the following impact acceleration.

| Servomotor model        | Impact acceleration          |
|-------------------------|------------------------------|
| SGLGW<br>SGLFW<br>SGLTW | 196 m/s <sup>2</sup> × twice |
| SGLC                    | 98 m/s <sup>2</sup> × twice  |

- Installation site: An environment that satisfies the following conditions
- · Indoors and free of corrosive or explosive gases
- · Well-ventilated and free of dust and moisture
- · Facilitates inspection and cleaning
- · Free of high magnetic field

#### 2.1.2 SERVOPACK Installation Environment

- Surrounding air temperature: 0°C to 55°C
- Ambient humidity: 90% RH or less (with no condensation)
- Altitude: 1,000 m or less
- Vibration resistance: 4.9 m/s<sup>2</sup>
- Shock resistance: 19.6 m/s<sup>2</sup>
- Installation Precautions
- · Mounting in a Control Panel

To prevent the temperature around the SERVOPACK from exceeding 55°C, take into account the size of the control panel, the layout of the SERVOPACK, and the cooling method. For details, refer to 2.4 SERVOPACK Installation.

· Mounting Near a Heating Unit

To prevent the temperature around the SERVOPACK from exceeding 55°C, suppress radiant heat from the heating unit and temperature rise due to convection.

· Mounting Near a Vibration Source

To prevent vibration from being transmitted to the SERVOPACK, install a vibration isolator underneath the SERVOPACK.

#### 2.1.3 Installation Conditions for Applicable Standards

#### · Mounting to a Location Exposed to Corrosive Gas

Take measures to prevent exposure to corrosive gas. Corrosive gases will not immediately affect the SERVOPACK, but will eventually cause electronic components and contactor-related devices to malfunction.

#### · Other Locations

Do not mount the SERVOPACK in locations subject to high temperatures, high humidity, dripping water, cutting oil, dust, iron filings, or radiation.

Note: When storing the SERVOPACK with the power OFF, store it in an environment with the following temperature and humidity:

• -20°C to +85°C, 90% RH or less. (with no condensation)

# **2.1.3** Installation Conditions for Applicable Standards


| Applicable<br>Standards    | UL508C<br>EN50178, EN55011/A2 group1 classA, EN61000-6-2, EN61800-3,<br>EN61800-5-1, EN954-1, IEC61508-1 to 4  |
|----------------------------|--|
| Operating Conditions       | Overvoltage Category: III Pollution degree: 2 Protection class: IP10   |
| Installation<br>Conditions | UL Standard and Low Voltage Directive: Satisfy the conditions outlined in Σ-V Series AC SERVOPACK SGDV Safety Precautions (TOBP C710800 10) EMC Directive: Certification is required after installation in the user's machine under the conditions outlined in 2.5 EMC Installation Conditions of this manual. |

# **2.2** Linear Servomotor Installation

# **2.2.1** SGLGW and SGLGM Linear Servomotors (Coreless Type)


#### (1) Magnetic Way Installation

The SGLGM magnetic way comprises a U-channel steel track with opposing magnets attached to the inner faces. Make sure that no foreign particles (magnetic objects) are caught between the magnets when installing the magnetic way.



Use the following procedure to install SGLGM magnetic ways.

1. After checking the magnetic way's two mounting reference surfaces, place the magnetic way on the reference surface of the machine base, making sure that hands are kept clear.



2. Place the magnetic way on the reference surface of the machine and secure it with bolts.


| Magnetic Way Model<br>SGLGM- | Bolt size | Tightening torque (N·cm) |  |
|------------------------------|-----------|--------------------------|--|
| 30□□□□                       | M4        | 360 to 500               |  |
| 40000                        | M5        | 720 to 1010              |  |
| 60000                        | 1413      | 720 to 1010              |  |

Note: Use hexagonal socket head bolts (tensile strength Class 10.9).

#### 2.2.1 SGLGW and SGLGM Linear Servomotors (Coreless Type)

**3.** When joining magnetic ways together, place the second magnetic way temporarily in line with and at least 30 mm apart from the first magnetic way.

Next, after aligning the angles of bolt sockets on the magnetic way's connecting surfaces, move the second magnetic way to join the first magnetic way. Connect the second and first magnetic ways together. And, after confirming the mounting position, secure the second magnetic way using bolts. Make sure that fingers do not get jammed due to the magnetic attraction between magnetic ways.




## (2) Moving Coil Installation

The SGLGW moving coil is constructed of an aluminum base and a resin-coated coil winding section. Handle the moving coil with care and do not subject the coil winding section to shock. Doing so may cause injury or damage to the moving coil.


Use the following procedure to install the SGLGW moving coil.

1. Insert the coil winding section of the moving coil between the magnets of the magnetic way that has already been installed. Next, install the moving coil on the movable table supported by the linear guide. Install the moving coil on the movable table supported by the linear guide. Make sure that the air gap between the moving coil's coil winding section and magnetic way's magnets is the specified distance.



The relationship between the dimensions and positioning between the moving coil's coil winding section and magnetic ways's magnets is shown here. Maintain the following air gaps when installing. Make sure that the moving coil and magnetic way do not interfere with each other during the stroke.

| Moving Coil Model           | Dimensions in mm |               |  |
|-----------------------------|------------------|---------------|--|
| Moving Coil Model<br>SGLGW- | Air gap<br>G1    | Air gap<br>G2 |  |
| 30A050□□                    | $0.85 \pm 0.3$   | 1 ± 0.3       |  |
| 30A080□□                    | $0.95 \pm 0.3$   | 1 ± 0.3       |  |
| 40A□□□□                     | $0.8 \pm 0.3$    | 1 ± 0.3       |  |
| 60A□□□□                     | $0.8 \pm 0.3$    | 1 ± 0.3       |  |



**2.** Move the moving coil back and forth several times over the magnetic way from end to end, making sure that the moving coil and magnetic way are not touching each other and that no foreign objects such as magnetic particles are present.


#### 2.2.2 SGLFW and SGLFM Linear Servomotors (F-type Iron Core)

# **2.2.2** SGLFW and SGLFM Linear Servomotors (F-type Iron Core)

#### (1) Magnetic Way Installation


The SGLFM magnetic way is packed with a cardboard sheet covering the magnetic surface, above which is a thin, rectangular steel plate.

The steel plate is a dummy plate used to reduce the influence of magnetic force on the surrounding environment. When removing the plate, make sure that fingers are kept clear and that the magnet and magnet protection cover are not damaged.



Use the following procedure to install the SGLFM magnetic way.

- 1. Remove the dummy plate used to reduce magnetic force and the cardboard sheet from the magnetic way's magnetic surface.
- **2.** Align the reference marks (approx. 4-mm dia. indentations) on the side of the magnetic way with the reference surface of the machine base, keeping fingers clear to prevent injury.




**3.** While placing the magnetic way on the machine base reference surface, secure it with bolts.

| Magnetic Way Model<br>SGLFM- | Bolt size | Tightening torque (N·cm) |
|------------------------------|-----------|--------------------------|
| 20000                        | M4        | 360 to 500               |
| 35□□□□                       | 1714      | 300 to 300               |
| 50000                        | M5        | 720 to 1010              |


Note: Use hexagonal socket head bolts (tensile strength Class 10.9).

Note: The magnetic way's magnets exert strong magnetic attraction. Make sure that steel bolts or wrenches are kept away from the magnets. Always use bolts with a head height according to the dimensions shown in the following table.

| Magnet Way Model<br>SGLFM- | Bolt size | Head height K<br>in mm |
|----------------------------|-----------|------------------------|
| 20000                      | M4        | 4.2 max.               |
| 35□□□□                     | 1714      | 4.2 max.               |
| 50000                      | M5        | 5.2 max.               |



4. When joining magnetic ways together, place the second magnetic way temporarily in line with and at least 30 mm apart from the first magnetic way. Next, match the direction of the magnetic ways (using the indentations as reference (approx. dia. 4 mm)). (Refer to the diagram in step 2.) Next, while holding the magnetic ways down so that they are not raised, push the second magnetic way against the first magnetic way and secure it with bolts. The magnetic ways may snap together due to the strong magnetism. Keep fingers clear to avoid injury.



Note: To ensure your safety, install the moving coil before installing the second and subsequent magnetic ways. For details, refer to (2) Moving Coil Installation.


#### 2.2.2 SGLFW and SGLFM Linear Servomotors (F-type Iron Core)

## (2) Moving Coil Installation

The SGLFW moving coil is constructed of an aluminum or steel base and iron core, with a resin-coated coil winding section. Make sure that the coil winding section is not subjected to shock during installation. Shock may cause injury or damage to the moving coil.

Use the following procedure to install the SGLFW moving coil.


 Install the moving coil on the movable table supported by the linear guide in line with the already installed magnetic way.
 Make sure that the air gaps between the moving coil and magnetic way's magnets is the specified distance.




Maintain the following air gaps when installing. Make sure that the moving coil and magnetic way do not interfere with each other during the stroke.

| Moving Coil Model           | Dimensions in mm |                |                     |
|-----------------------------|------------------|----------------|---------------------|
| Moving Coil Model<br>SGLFW- | Н                | Р              | Air gap<br>G        |
| 20A□□□A□                    | 45 ± 0.1         | $22 \pm 0.2$   |                     |
| 35A□□□A□                    | 43 ± 0.1         | $21 \pm 0.2$   | $1 \pm 0.3$ (0.8) * |
| 50A□□□B□                    | $58 \pm 0.1$     | $25.8 \pm 0.2$ | (515)               |

<sup>\*</sup> The value in parentheses is the dimension when the magnet protection cover is used.




Linear servomotor side view (Viewed from the side where the cable extends from the moving coil)



#### 2.2.2 SGLFW and SGLFM Linear Servomotors (F-type Iron Core)

Insert a thin nonmagnetic (preferably resin) sheet (approximately 0.5-mm thick) in the air gap between the moving coil and magnetic way. Then, and move the moving coil toward the magnetic way.





Always be aware of the strong magnetism of the magnetic way and keep fingers and tools at a safe distance, especially when the moving coil is near the magnetic way. The moving coil will be strongly attracted to the magnetic way. When the specified dimensions of the air gaps between the moving coil and the magnetic way are secured, it is not necessary to insert nonmagnetic sheets into the air gaps. (see the table of dimensions in step 1.)

**3.** Move the moving coil back and forth several times over the magnetic way from end to end, making sure that the moving coil is not touching the magnetic way and that no foreign objects (such as magnetic particles) are present. Use a nonmagnetic (brass or stainless steel) gap gauge to check that the air gap between the moving coil and the magnetic way is even.

# (3) Magnetic Attraction

The linear servomotor is constructed of an opposing moving coil and magnetic way. Therefore, the moving coil is subjected to magnetic attraction as shown in the following table (calculated value). Consider the magnetic attraction when designing the system.

| Moving Coil<br>Model<br>SGLFW- | Air gap G* <sup>1</sup><br>in mm | Magnetic attraction F*2 | Magnetia B  |
|--------------------------------|----------------------------------|-------------------------|---|
| 20A090A□                       |                                  | 410                     | Magnetic   Magnetic |
| 20A120A□                       |                                  | 600                     | F   |
| 35A120A□                       | 0.7                              | 1100                    |   |
| 35A230A□                       |                                  | 2100                    |   |
| 50A200B□                       |                                  | 2700                    | -   |

- \*1. Indicates an air gap value of -0.3 mm relative to the design value.
- \*2. Indicates the magnetic attraction for the maximum force.

2.2.3 SGLTW and SGLTM Linear Servomotors (T-type Iron Core)

# **2.2.3** SGLTW and SGLTM Linear Servomotors (T-type Iron Core)

# (1) Magnetic Way Installation

The SGLTM magnetic way is packed with two yokes securely positioned with an aluminum spacer.




Do not remove the spacers until the magnetic way is temporarily fixed to the system.


**IMPORTANT** 

Use the following procedure to install the SGLTM magnetic way.


1. With the spacers attached, place the magnetic way on both positioning steps. Make sure that the machine and magnetic way are not scratched or dented when positioning the magnetic way. Set the dimensions of these positioning steps to match the W2 dimensions in the following table.



|                              | Dimensions in mm            |   |  |
|------------------------------|-----------------------------|---|--|
| Magnetic Way<br>Model SGLTM- | W1 (Dimensions at shipment) | W2<br>(Recommended machine<br>base value) |  |
| 200000                       | 71.5 ± 1                    | 70 + 0.15                                 |  |
| 35□□□□                       | 71.5 ± 1                    | 70 ± 0.13                                 |  |
| 40000                        | 113 ± 1                     | 111.8 + 0.15                              |  |
| 800000                       | 113 ± 1                     | 111.0 ± 0.13                              |  |
| 35□□□H                       | 91.5 ± 1                    | 90 ± 0.15                                 |  |
| 50□□□H                       | 71.5 ± 1                    | 70 ± 0.13                                 |  |



**2.** Insert the mounting bolts into one of the two magnetic way yokes and tighten lightly by hand. Next, while firmly holding down the magnetic way yoke onto the positioning step, tighten the bolts firmly.



| Magnetic Way Model<br>SGLTM- | Bolt size | Tightening torque (N⋅cm) |
|------------------------------|-----------|--------------------------|
| 20000                        | M6        | 1220 to 1710             |
| 35□□□□                       | 1410      | 1220 to 1710             |
| 35□□□H                       | M6        | 1220 to 1710             |
| 50□□□H                       | 1410      | 1220 10 1710             |


Note: The following conditions apply to these values.

- · Machine material: Steel
- Hexagonal socket head bolts (tensile strength Class 10.9)

#### 2.2.3 SGLTW and SGLTM Linear Servomotors (T-type Iron Core)

- **3.** After removing the spacer fixing bolts from the side of the already installed magnetic way yoke, firmly hold the other magnetic way yoke onto the positioning step, while firmly tightening the bolts. Make sure that the magnetic way yokes do not slip into the path of the moving coil.
- **4.** Unscrew the rest of the spacer fixing bolts to remove the spacer. Check where the spacer was fixed to see if there are any mounting holes. If there are, insert bolts into them and tighten the bolts.
- **5.** When joining magnetic ways together, place the second magnetic way temporarily in line with and at least 30 mm apart from the first magnetic way. Next, while pushing the second magnetic way against the first magnetic way, secure it with bolts. Keep fingers clear to prevent them from being jammed between the magnetic ways due to the magnetic attraction pulling the magnetic ways together.

Follow the same procedure as in steps 1 to 4 to install subsequent magnetic ways.




Note: To ensure your safety, install the moving coil before installing second and subsequent magnetic ways. For details, refer to (2) Moving Coil Installation.

## (2) Moving Coil Installation

The SGLTW moving coil is constructed of an aluminum or steel base and iron core, with a resin-coated coil winding section. Make sure that the coil winding section is not subjected to shock during installation. Shock may damage the moving coil.

Use the following procedure to install the SGLTW moving coil.

 Install the moving coil on the movable table supported by the linear guide in line with the already installed magnetic way.
 Make sure that the air gaps between the moving coil and magnetic way's magnets is the specified distance.





Maintain the following air gaps when installing. Make sure that the moving coil and magnetic way do not interfere with each other during the stroke.

| Moving Coil     | Dimensions in mm |                |                  |  |  |  |
|-----------------|------------------|----------------|------------------|--|--|--|
| Model<br>SGLTW- | Н                | А              | Air gap<br>G1,G2 |  |  |  |
| 20A□□□A□        | $55 \pm 0.3$     | 15 ± 0.1       | $1 \pm 0.3$      |  |  |  |
| 35A□□□A□        | $70 \pm 0.3$     | 13 ± 0.1       | (0.8)*           |  |  |  |
| 35A□□□H□        | $70 \pm 0.3$     | $15 \pm 0.1$   | $1 \pm 0.3$      |  |  |  |
| 50A□□□H□        | $85 \pm 0.3$     | $19.1 \pm 0.1$ | (0.8)*           |  |  |  |


<sup>\*</sup> The value in parentheses is the dimensions when the magnet protection cover is used.

### 2.2.3 SGLTW and SGLTM Linear Servomotors (T-type Iron Core)





2. Insert a thin nonmagnetic (preferably resin) sheet (approximately 0.5-mm thick) in the air gap between the moving coil and magnetic way. Then, move the moving coil slowly toward the magnetic way.





Always be aware of the strong magnetism of the magnetic way and keep fingers and tools at a safe distance, especially when the moving coil is near the magnetic way. The moving coil will be strongly attracted to the magnetic way. When the specified dimensions of the air gaps between the moving coil and the magnetic way are secured, it is not necessary to insert nonmagnetic sheets into the air gaps. (see the table of dimensions in step 1.)

**3.** Move the moving coil back and forth several times over the magnetic way from end to end, making sure that the moving coil is not touching the magnetic way and that no foreign objects (such as magnetic particles) are present. Use a nonmagnetic (brass or stainless steel) gap gauge to check that the air gap between the moving coil and magnetic way is even (tolerance:  $\pm$  0.3 mm).

### 2.2.3 SGLTW and SGLTM Linear Servomotors (T-type Iron Core)


## (3) Magnetic Attraction

The linear servomotor is constructed of an opposing moving coil and magnetic way. So, the magnetic attraction is offset when the air gaps between the moving coils and the magnetic way are even.

However, achieving an even air gap is difficult due to the accuracy of the linear servomotor itself and the customer's machine, and because of errors in the assembly of the linear servomotor at installation. Consider the magnetic attraction values (calculated values) shown in the following table when designing the system.

| Moving Coil<br>Model<br>SGLTW- | Air gap<br>G1* <sup>1</sup><br>in mm | Air gap<br>G2* <sup>1</sup><br>in mm | Magnetic<br>attraction<br>F1*2<br>(N) | Magnetic<br>attraction<br>F2*2<br>(N) | Attraction difference $\Delta F$ (N) |
|--------------------------------|--------------------------------------|--------------------------------------|---------------------------------------|---------------------------------------|--------------------------------------|
| 20A170A□                       | 1.3                                  | 0.7                                  | 760                                   | 1030                                  | 270                                  |
| 20A320A□                       | 1.5                                  | 0.7                                  | 1510                                  | 2040                                  | 530                                  |
| 35A170A□                       |                                      |                                      | 1330                                  | 1800                                  | 470                                  |
| 35A170H□                       | 1.3                                  | 0.7                                  | 1330                                  | 1800                                  | 470                                  |
| 35A320A□                       |                                      |                                      | 2650                                  | 3570                                  | 920                                  |
| 50A170H□                       | 1.3                                  | 0.7                                  | 1900                                  | 2600                                  | 700                                  |

- \*1. Indicates an air gap when one side is +0.3 mm and the other side -0.3 mm relative to the design values.
- \*2. Indicates the magnetic attraction at maximum force.



### (1) Components

The magnetic way consists of the following parts.

- Pipe (made of stainless steel)
- Magnet in the pipe

Make sure not to get your fingers or other objects caught in the magnetic way because a strong magnetic attraction is generated in the area surrounding the magnetic way.

The moving coil consists of the following parts.

- Outer frame (made of aluminum)
- Resin section for protecting winding
- Cables for motor main circuit or hall sensor

If force is applied to the resin section, injury or damage to the product may result.


### (2) State of Delivery

This product is delivered with a resin piece inserted between the moving coil and the magnetic way to protect the winding.




IMPORTANT

For safety reasons, mount the linear servomotors onto a machine with the moving coil attached to the magnetic way of the linear servomotor. If the moving coil must be separated from the magnetic way for any reason, make sure not to get your fingers or other objects caught in the magnetic way. A strong magnetic attraction is generated.



### (3) Installation Procedure

- 1. Install the linear guide and the parts for supporting the magnetic way on the machine side.
  - Set the positions of the parts for supporting the magnetic way after checking the outer dimension of the magnetic way referring to *Table 2.1*.
  - In most case, the length of the magnetic way is regarded as the side where the nameplate 0.1 mm thick indicating the ratings and a caution about the magnetic attraction.
  - Construct the machine so that the difference between the centers of the cross-sectional surfaces of the magnetic way and the moving coil should be within 0.2 mm. Refer to the following diagram.



- **2.** Take the product out of the package with the moving coil and the magnetic way being combined (same as the state when the product is delivered).
- **3.** Insert both ends of the magnetic way in the supporting parts, and fix them with bolts.
  - Refer to Table 2.1 Dimensions of the Magnetic Way (Selected models only).





Table 2.1 Dimensions of the Magnetic Way (Selected models only)

| Magnetic<br>Way<br>Model<br>SGLCM- | Total<br>Length<br>of Mag-<br>netic<br>Way L1<br>(mm) | Position<br>of<br>Support<br>Section<br>L2 (mm) | Driving<br>Range<br>of Coil<br>Assem-<br>bly<br>L3 (mm) | Length<br>of Sup-<br>port<br>Section<br>L4 (mm) | Range<br>outside<br>the<br>Guaran-<br>teed<br>Force *<br>L5 (mm) | Range<br>within<br>the<br>Guaran-<br>teed<br>Force<br>L6 (mm) | Range<br>outside<br>the<br>Guaran-<br>teed<br>Force *<br>L7 (mm) |
|------------------------------------|---|---|---|---|--|---|--|
| D16300A                            | $300 \pm 1.6$   | 30  | 240   | 25  | $37.5 \pm 0.3$   | $225 \pm 1.2$   | 37.5   |
| D16510A                            | $510 \pm 2.5$   | 45  | 420   | 40  | $52.5 \pm 0.3$   | $405 \pm 2.1$   | 52.5   |
| D16750A                            | $750 \pm 3.0$   | 45  | 660   | 40  | $52.5 \pm 0.3$   | $645 \pm 2.5$   | 52.5   |
| D20350A                            | $350 \pm 1.6$   | 35  | 280   | 30  | $45 \pm 0.3$   | $260 \pm 1.2$   | 45   |
| D20590A                            | $590 \pm 2.5$   | 50  | 490   | 45  | $60 \pm 0.3$   | $470 \pm 2.1$   | 60   |
| D20870A                            | $870 \pm 3.0$   | 50  | 770   | 45  | $60 \pm 0.3$   | $750 \pm 2.5$   | 60   |
| D25450A                            | $450 \pm 1.6$   | 45  | 360   | 37  | $57.5 \pm 0.3$   | $335 \pm 1.2$   | 57.5   |
| D25750A                            | $750 \pm 2.5$   | 60  | 630   | 52  | $72.5 \pm 0.3$   | $605 \pm 2.1$   | 72.5   |
| D251110A                           | $1110 \pm 3.0$  | 60  | 990   | 52  | $72.5 \pm 0.3$   | $965 \pm 2.5$   | 72.5   |
| D32600A                            | $600 \pm 1.6$   | 60  | 480   | 52  | $75 \pm 0.3$   | $450 \pm 1.2$   | 75   |
| D321020A                           | $1020 \pm 2.5$  | 90  | 840   | 82  | $105 \pm 0.3$  | $810 \pm 2.1$   | 105  |
| D321500A                           | $1500 \pm 3.0$  | 90  | 1320  | 82  | $105 \pm 0.3$  | $1290 \pm 2.5$  | 105  |

<sup>\*</sup>If a part of the moving coil is located within this range, predetermined characteristics cannot be satisfied.



- 4. After mounting the movable table provided by the customer on the linear guide, transfer the movable table onto the moving coil and secure them with bolts.
  - Carefully lay wiring so that no cables are caught, and fix them to the movable table.
  - For the recommended tightening torque of the bolts for fixing the moving coil, refer to *Table 2.2 Moving Coil and Recommended Tightening Torque*.

Table 2.2 Moving Coil and Recommended Tightening Torque

| Moving Coil<br>Model<br>SGLCW- | Nominal Diameter of Bolts | Tightening torque<br>(N·cm) |
|--------------------------------|---------------------------|-----------------------------|
| D16□□□□                        | M3                        | 100                         |
| D200000                        | M4                        | 220                         |
| D25□□□□                        | M5                        | 450                         |
| D32□□□□                        | M6                        | 760                         |

Note: Use hexagon socket head cap screws made of austenite stainless steel (equivalent to the strength class A2-70.)

- **5.** Remove the part made of resin between the moving coil and the magnetic way. Be careful not to get your fingers or other objects caught between the moving coil and the magnetic way because a strong magnetic attraction is generated between them.
- **6.** Perform several full strokes with the movable table, and make sure that the table may not come into contact with the magnetic way. (The size of the gaps is not specified.)

### (4) Others

#### ■ Magnetic Attraction between Moving Coil and Magnetic Way

Because the steel yoke is embedded in the moving coil to generate force, magnetic attraction generates between the moving coil and the magnetic way. When the gap between the moving coil and the magnetic way is uniform, the magnetic attraction on the moving coil is offset.

A uniform gap is difficult to obtain, however, because it depends upon the precision of the moving coil and the magnetic way products, deflection of the magnetic way, precision of the equipment of the customer, and assembly error at the time of mounting the motors. In case of non-uniform gap, the attraction shown in *Table 2.3* is generated. When designing the equipment, take into account the attraction.


| Table 2.3 | Magnetic Attraction | (calculated value) |
|-----------|---------------------|--------------------|
|-----------|---------------------|--------------------|

| Moving Coil Model<br>SGLCW- | Design Value of<br>Gap<br>(mm) | Gap G1 *1<br>(mm) | Gap G2 <sup>*1</sup><br>(mm) | Difference of<br>Attraction<br>F1-F2*2<br>(N) |
|-----------------------------|--------------------------------|-------------------|------------------------------|---|
| D16A085A□                   |                                |                   |                              | 20  |
| D16A115A□                   | 1.0                            | 0.3               | 1.7                          | 30  |
| D16A145A□                   |                                |                   |                              | 40  |
| D20A100A□                   |                                |                   |                              | 25  |
| D20A135A□                   | 1.25                           | 0.4               | 2.1                          | 38  |
| D20A170A□                   |                                |                   |                              | 50  |
| D25A125A□                   |                                |                   |                              | 50  |
| D25A170A□                   | 1.5                            | 0.5               | 2.5                          | 75  |
| D25A215A□                   |                                |                   |                              | 100   |
| D32A165A□                   |                                |                   |                              | 80  |
| D32A225A□                   | 1.75                           | 0.5               | 3.0                          | 120   |
| D32A285A□                   |                                |                   |                              | 160   |

<sup>\*1.</sup> Indicates the gap of the machine when a dislocation of approximately 70% in comparison to the designed value occurs.

Note: For the conditions other than those mentioned above, contact Yaskawa representative separately.

The figure shown on the right is an example in which a non-uniform gap occurs. Actually, magnetic attraction may be generated and extended in all directions because of an assembling error or other reasons.




<sup>\*2.</sup> Indicates the magnetic attraction at the time of maximum force.

## ■ Leakage Flux of the Magnetic Way

The following table shows the leakage flux of the magnetic way.

Table 2.4 Leakage Flux

|                             | Diameter of      | Places Where the Leakage Flux is 10<br>Gausses or More |                    |  |  |
|-----------------------------|------------------|--|--------------------|--|--|
| Moving Coil Model<br>SGLCW- | i Madhetic way i |  | Diameter<br>B (mm) |  |  |
| D16□□□                      | 16               | 80 or less   | 176 or less        |  |  |
| D20□□□                      | 20               | 100  | 220                |  |  |
| D25□□□                      | 25               | 120  | 265                |  |  |
| D32□□□                      | 32               | 140  | 312                |  |  |



# **2.3** Linear Scale Installation and Adjustment

## 2.3.1 Installation Conditions

The magnetic flux leaked from a linear servomotor may lead to malfunction of the linear scale. To avoid such malfunction, determine the linear scale installation location in such environment that the magnetic field strength on the linear scale mounted surface satisfy the following condition.

For the environmental conditions other than magnetic field, refer to the specifications of the corresponding linear scale.

| Manufacturer         | Model       | External Magnetic Field<br>Strength |
|----------------------|-------------|-------------------------------------|
|                      | SR75/77     | 5 [mT] max.                         |
| Magnescale Co., Ltd. | SR85/87     | 5 [m1] max.                         |
|                      | SL710/PL101 | 0.5 [mT] max.                       |
| Mitutoyo Corporation | ST78□A      | 3 [mT] max.                         |


The guideline for installation position of each linear servomotor in relation to the linear scale is shown in the following pages.

When the linear scale mounting material and/or the linear servomotor magnetic way mounting material are magnetic, installing the linear servomotor on the position described on the following pages may not satisfy the condition of magnetic field strength. Use non-magnetic material such as stainless steel and aluminium for the mounting body, or provide magnetic shielding structure such as magnetic separator between the linear servomotor magnetic way and the linear scale, and install the linear scale on the position described in the following pages.

If your machine configuration does not allow the installation of the linear servomotor and the linear scale such way as described on the following pages, measure the magnetic field strength on the position where the linear scale is actually installed, and take a counter measure for the magnetic field strength not to exceed the value specified in the above table.


## 2.3.1 Installation Conditions

# (1) SGLGM




| Magnetic Way Model | Distance from Magnetic Way Surface (mm) |          |         |         |        |         |
|--------------------|---|----------|---------|---------|--------|---------|
| SGLGM-             | Α                                       | A'       | В       | С       | D      | X       |
| 90□□□□             | 10 min.                                 | 160 min. | 70 min. | 70 min. | 5 min. | 42 min. |

# (2) SGLFM




| Magnetic Way Model | Distance from Magnetic Way Surface (mm) |            |            |             |            |            |            |              |
|--------------------|---|------------|------------|-------------|------------|------------|------------|--------------|
| SGLFM-             | Α                                       | A'         | В          | B'          | С          | D          | D          | Х            |
| 1Z□□□□             | 10<br>min.                              | 10<br>min. | 70<br>min. | 120<br>min. | 20<br>min. | 20<br>min. | 30<br>min. | 22.5<br>min. |

#### (3) SGLTM



| Magnetic Way Model | Distance from Magnetic Way Surface (mm) |         |         |         |           |  |
|--------------------|---|---------|---------|---------|-----------|--|
| SGLTM-             | Α                                       | A'      | В       | С       | Х         |  |
| 80□□□□             | 10 min.                                 | 10 min. | 30 min. | 20 min. | 22.5 min. |  |

# (4) SGLCM



| Magnetic Way Model SGLCM- | Distance A from Magnetic Way Surface (mm) |
|---------------------------|---|
| D16A□□□□                  | 60 min.                                   |
| D20A□□□□□                 | 70 min.                                   |
| D25A□□□□□                 | 90 min.                                   |
| D32A□□□□□                 | 130 min.                                  |

#### 2.3.2 Installation


## 2.3.2 Installation

Install the linear scale so that the linear servomotor forward direction and linear scale count up direction are the same.




If the linear servomotor forward direction and linear scale count up direction do not match and the linear servomotor is run in this state, the linear servomotor may not operate or may overrun.

When using  $\Sigma$ -V series linear servomotors, the linear servomotor forward direction (moving coil's movement direction when current flows through phases U, V, and W, in that order) is toward the side from which the linear servomotor main circuit cable is extended. The analog 1-V p-p voltage input from the incremental linear scale to the serial converter unit is counted during phase A (cos signal) progression.




Note: When the direction of the linear servomotor and the direction in which the linear scale counts pulses are reversed because of wiring or other factors, set the parameter Pn080.1=1 (Sets phase B lead as phase sequence of U, V, W).

## (1) Heidenhain Linear Scale



When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the right.


### (2) Renishaw Linear Scale



When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the left.


## (3) Mitutoyo Linear Scale

### ■ ST781A□, ST783A□, ST788A□, and ST789A□



When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the left.

#### ■ ST782A□ and ST784A□




When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the right.

#### 2.3.3 Adjustment


### (4) Magnescale Linear Scale

## ■ SR75-□□□R, SR85-□□□R, SR77-□□□R, and SR87-□□□R




When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the right.

### ■ SR75-□□□L, SR85-□□□L, SR77-□□□L, and SR87-□□□L



When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the right.

#### ■ SL700, SL710, SL720, and SL730



When installed as shown in the diagram on the left, operation is performed in the forward direction when the sensor head is moved to the left.

# 2.3.3 Adjustment

When the linear scale is an open type, adjust the head installation. For details on the adjustment method, contact the manufacturer of the scales.

When the linear scale is a sealed type, adjustment is not required. However, the dimensional tolerances for installation must be maintained.

## 2.4 SERVOPACK Installation


### 2.4.1 Orientation

The SERVOPACK is available in models that are base-mounted, models that are rack-mounted, and models that are duct-ventilated. In any case, mount the SERVO-PACK with a vertical orientation.


Firmly secure the SERVOPACK to the mounting surface, using either two or four mounting holes depending on the SERVOPACK capacity.

Note: For SERVOPACKs of command option attachable type, installation conditions may differ depending on the attached option module. For details, refer to the user's manual for each option module.

#### · Base-mounted




#### · Rack-mounted



## 2.4.1 Orientation

## • Duct-ventilated



## 2.4.2 Installation Standards

Observe the standards for mounting SERVOPACKs in control panels, including those for the mounting SERVOPACKs side by side in one control panel as shown in the following illustration.

Note: For SERVOPACKs of command option attachable type, installation conditions may differ depending on the attached option module. For details, refer to the user's manual for each option module.


### · SERVOPACK Mounting Orientation

Mount the SERVOPACK vertically to the wall, with the front panel (the side with the panel operator display) facing out.

#### Cooling

Refer to the following diagram and leave sufficient space for cooling by fans and natural convection.

## Mounting SERVOPACKs Side by Side in a Control Panel



Leave sufficient space on each side and at the top and the bottom of each SERVO-PACK. The width on each side varies in accordance with the models of the SERVO-PACKS used.

| SERVOPACK Model  | Side                       |       | Top and bottom |
|--|----------------------------|-------|----------------|
| SGDV-  | Left                       | Right | rop and bottom |
| R70F, R90F, 2R1F,<br>R70A, R90A, 1R6A, 2R8A                                  | 1 mm or more               |       |                |
| 2R8F, 3R8A, 5R5A, 7R6A   | 1 mm or more 10 mm or more |       | 40 mm or more  |
| 120A, 180A, 200A, 330A,<br>550A, 1R9D, 3R5D, 5R4D,<br>8R4D, 120D, 170D, 260D | 10 mm or more              |       |                |

Also install cooling fans above the SERVOPACKs to disperse local pockets of warmer air around the SERVOPACKs.

#### 2.4.2 Installation Standards

#### · Inside the Control Panel

The conditions inside the control panel should be the same as the environmental conditions of the SERVOPACK. Refer to 2.1.2 SERVOPACK Installation Environment.

The SGDV-□□□□□□B SERVOPACKs have an Installation Environment monitor (Un022). With this monitor, operation conditions in the installation environment can be observed and measured.

The value shown on this monitor should be equal to or less than 100% for optimum operating conditions.

If this value is over 100%, one of the following measures must be taken to ensure safe operation and a long product life.

Improve air circulation around SERVOPACKs.

Minimum Air Circulation Rate

Top (10 mm): 0.5 m/s Bottom (10 mm): 0.2 m/s

To improve the air circulation to meet these minimum standards and to lower the percentage shown on the monitor, widen the space between the SERVOPACKs or lower the temperature of the surrounding air.

#### <Note>

For every increase of 10°C, the percentage shown on the monitor will also increase by approximately ten.

## **2.5** EMC Installation Conditions


This section describes the recommended installation conditions that satisfy EMC guidelines for each model of the SGDV SERVOPACK. The conditions required for the standard type (base-mounted) of SERVOPACK are described. Refer to this section for other SERVOPACK models such as the rack-mounted types as well.

This section describes the EMC installation conditions satisfied in test conditions prepared by Yaskawa. The actual EMC level may differ depending on the actual system's configuration, wiring, and other conditions. However, because this product is built-in, check that the following conditions are still met after being installed in the user's product.

The applicable standards are EN55011/A2 group 1 class A, EN61800-3, and EN61000-6-2.

## **2.5.1** SGDV-


■ Single-phase 100 V, SGDV-□□□F05A (□□□ = R70, R90, 2R1, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (\$)   | Main circuit cable                   | Shield cable  |


## 2.5.1 SGDV-DDDD05D (Analog Pulse Model)

■ Three-phase 200 V, SGDV-□□□A05B (□□□ = R70, R90, 1R6, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (\$)   | Main circuit cable                   | Shield cable  |


■ Three-phase 200 V, SGDV-□□□A05A (□□□ = R70, R90, 1R6, 2R8, 3R8, 5R5, 7R6)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |


## 2.5.1 SGDV-DDDD05D (Analog Pulse Model)

## ■ Three-phase 200 V, SGDV-120A05A



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (\$)   | Main circuit cable                   | Shield cable  |


# ■ Three-phase 200 V, SGDV-□□□A05A (□□□ = 180, 200, 330)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| 1      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |


## 2.5.1 SGDV-DDDD05D (Analog Pulse Model)

## ■ Three-phase 200 V, SGDV-550A05A



| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (5)    | Main circuit cable                   | Shield cable     |
| 6      | Regenerative resistor unit cable     | Non-shield cable |

■ Three-phase 400 V, SGDV-□□□D05A (□□□ = 1R9, 3R5, 5R4, 8R4, 120, 170)




| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| 0      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Control power cable                  | Shield cable  |
| 6      | Main circuit cable                   | Shield cable  |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- \*2. Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
  - Model number: FN2070-6/07 (SCHAFFNER)
- For more information on this filter, refer to Σ-V Series Product Catalog. (KAEP S800000 42)

## 2.5.1 SGDV-DDDD05D (Analog Pulse Model)

## ■ Three-phase 400 V, SGDV-260D05A




| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (5)    | Control power cable                  | Shield cable     |
| 6      | Main circuit cable                   | Shield cable     |
| 7      | Regenerative resistor unit cable     | Non-shield cable |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
   Model number: FN2070-6/07 (SCHAFFNER)
- \*3. For more information on this filter, refer to *Σ-V Series Product Catalog*. (KAEP S800000 42)

# **2.5.2** SGDV-□□□□15□ (M-II Model)


■ Single-phase 100 V, SGDV-□□□F15A (□□□ = R70, R90, 2R1, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-II communication cable  | Shield cable  |


## 2.5.2 SGDV-□□□□15□ (M-II Model)

■ Three-phase 200 V, SGDV-□□□A15B (□□□ = R70, R90, 1R6, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-II communication cable  | Shield cable  |


■ Three-phase 200 V, SGDV-□□□A15A (□□□ = R70, R90, 1R6, 2R8, 3R8, 5R5, 7R6)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-II communication cable  | Shield cable  |


## 2.5.2 SGDV-□□□□15□ (M-II Model)

## ■ Three-phase 200 V, SGDV-120A15A



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-II communication cable  | Shield cable  |


# ■ Three-phase 200 V, SGDV-□□□A15A (□□□ = 180, 200, 330)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-II communication cable  | Shield cable  |


## 2.5.2 SGDV-□□□□15□ (M-II Model)

## ■ Three-phase 200 V, SGDV-550A15A



| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (5)    | Main circuit cable                   | Shield cable     |
| 6      | Regenerative resistor unit cable     | Non-shield cable |
| Ø      | MECHATROLINK-II communication cable  | Shield cable     |

■ Three-phase 400 V, SGDV-□□□D15A (□□□ = 1R9, 3R5, 5R4, 8R4, 120, 170)




| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| 0      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Control power cable                  | Shield cable  |
| 6      | Main circuit cable                   | Shield cable  |
| 7      | MECHATROLINK-II communication cable  | Shield cable  |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
   Model number: FN2070-6/07 (SCHAFFNER)
- \*3. For more information on this filter, refer to Σ-V Series Product Catalog. (KAEP S800000 42)

#### 2.5.2 SGDV-□□□□15□ (M-II Model)

# ■ Three-phase 400 V, SGDV-260D15A




| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (5)    | Control power cable                  | Shield cable     |
| 6      | Main circuit cable                   | Shield cable     |
| 7      | Regenerative resistor unit cable     | Non-shield cable |
| 8      | MECHATROLINK-II communication cable  | Shield cable     |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- \*2. Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
  - Model number: FN2070-6/07 (SCHAFFNER)
- \*3. For more information on this filter, refer to *Σ-V Series Product Catalog*. (KAEP S800000 42)

# **2.5.3** SGDV-□□□□25□ (M-III Model)


■ Single-phase 100 V, SGDV-□□□F25A (□□□ = R70, R90, 2R1, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (\$)   | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-III communication cable | Shield cable  |


# 2.5.3 SGDV-□□□□25□ (M-III Model)

■ Three-phase 200 V, SGDV-□□□A25B (□□□ = R70, R90, 1R6, 2R8)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-III communication cable | Shield cable  |


■ Three-phase 200 V, SGDV-□□□A25A (□□□ =R70, R90, 1R6, 2R8, 3R8, 5R5, 7R6)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-III communication cable | Shield cable  |


# 2.5.3 SGDV-□□□□25□ (M-III Model)

# ■ Three-phase 200 V, SGDV-120A25A



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-III communication cable | Shield cable  |


# ■ Three-phase 200 V, SGDV-□□□A25A (□□□ = 180, 200, 330)



| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| ①      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Main circuit cable                   | Shield cable  |
| 6      | MECHATROLINK-III communication cable | Shield cable  |


# 2.5.3 SGDV-□□□□25□ (M-III Model)

# ■ Three-phase 200 V, SGDV-550A25A



| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (\$)   | Main circuit cable                   | Shield cable     |
| 6      | Regenerative resistor unit cable     | Non-shield cable |
| 7      | MECHATROLINK-III communication cable | Shield cable     |

# ■ Three-phase 400 V, SGDV-□□□D25A (□□□ = 1R9, 3R5, 5R4, 8R4, 120, 170)




| Symbol | Cable Name                           | Specification |
|--------|--------------------------------------|---------------|
| 0      | I/O signal cable                     | Shield cable  |
| 2      | Cable for safety unit                | Shield cable  |
| 3      | Linear servomotor main circuit cable | Shield cable  |
| 4      | Linear scale connection cables       | Shield cable  |
| (5)    | Control power cable                  | Shield cable  |
| 6      | Main circuit cable                   | Shield cable  |
| 7      | MECHATROLINK-III communication cable | Shield cable  |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
   Model number: FN2070-6/07 (SCHAFFNER)
- \*3. For more information on this filter, refer to Σ-V Series Product Catalog. (KAEP S800000 42)

#### 2.5.3 SGDV-DDDD25D (M-III Model)

# ■ Three-phase 400 V, SGDV-260D25A



| Symbol | Cable Name                           | Specification    |
|--------|--------------------------------------|------------------|
| ①      | I/O signal cable                     | Shield cable     |
| 2      | Cable for safety unit                | Shield cable     |
| 3      | Linear servomotor main circuit cable | Shield cable     |
| 4      | Linear scale connection cables       | Shield cable     |
| (\$)   | Control power cable                  | Shield cable     |
| 6      | Main circuit cable                   | Shield cable     |
| 7      | Regenerative resistor unit cable     | Non-shield cable |
| 8      | MECHATROLINK-III communication cable | Shield cable     |

- \*1. Products that have received CE marking are recommended for the 24 VDC power supply.
- Install the following noise filter on the power line between the single-phase 200 V power supply and the 24 VDC power supply.
   Model number: FN2070-6/07 (SCHAFFNER)
- \*3. For more information on this filter, refer to *Σ-V Series Product Catalog*. (KAEP S800000 42)

# **2.5.4** SGDV-DDDDE5A (Command Option Attachable Type)

For SERVOPACKs of command option attachable type, EMC installation conditions may differ depending on the attached option module. For details, refer to the user's manual for each option module.

#### 2.5.5 Other Precautions

#### (1) Attachment Methods of Ferrite Cores

| One turn           | Two turn           |
|--------------------|--------------------|
| Cable Ferrite core | Cable Ferrite core |

#### (2) Recommended Ferrite Core

| Cable Name                           | Ferrite Core Model | Manufacturer    |
|--------------------------------------|--------------------|-----------------|
| Linear servomotor main circuit cable | ESD-SR-250         | NEC TOKIN Corp. |


# (3) Recommended Noise Filter and Surge Absorber

For more information on recommended noise filters and surge absorbers, refer to  $\Sigma$ -V Series Product Catalog. (KAEP S800000 42)

# (4) Fixing the Cable

Fix and ground the cable shield using a piece of conductive metal.

• Example of Cable Clamp



# (5) Shield Box

A shield box, which is a closed metallic enclosure, is effective as reinforced shielding against electromagnetic interference (EMI) from SERVOPACKs. The structure of the box should allow the main body, door, and cooling unit to be attached to the ground. The box opening should be as small as possible.

Note: Do not connect the digital operator and the analog monitor cable to the SERVOPACK during operations. Connect them only when the machinery is stopped during maintenance.

# 2.5.5 Other Precautions

# Wiring and Connection

This chapter describes how to set up the wiring and connections required for trial operation.

For more information on the wiring and connection, refer to the following manuals.

| • Σ-V Series User's Manual Design and Maintenance Linear Motor/ |
|---|
| Analog Voltage and Pulse Train Reference (SIEP S800000 47)      |
| • Σ-V Series User's Manual Design and Maintenance Linear Motor/ |
| MECHATROLINK-II Communications Reference (SIEP S800000 48)      |
| • Σ-V Series User's Manual Design and Maintenance Linear Motor/ |
| MECHATROLINK-III Communications Reference (SIEP S800000 65)     |
| • Σ-V Series User's Manual Design and Maintenance Linear Motor/ |

Command Option Attachable Type (SIEP S800000 66)

| 3.1 | Prec  | autions for Wiring                                     | 3-3    |
|-----|-------|--|--------|
| 3.2 | Syst  | em Configuration Diagram                               | 3-4    |
|     |       | Connecting to SGDV-□□□□□05□ SERVOPACK                  |        |
|     |       | (Analog Pulse Model)                                   | 3-4    |
|     | 3.2.2 | Connecting to SGDV-□□□□□15□ SERVOPACK                  |        |
|     |       | (M-II Model)   | 3-8    |
|     | 3.2.3 | Connecting to SGDV-□□□□□25□ SERVOPACK                  |        |
|     |       | (M-III Model)  | 3-12   |
|     | 3.2.4 | Connecting to SGDV-□□□□E5A SERVOPACK                   |        |
|     |       | (Command Option Attachable Type)                       | 3-16   |
| 3.3 | Main  | Circuit Wiring   | . 3-20 |
|     |       | Main Circuit Terminals                                 |        |
|     | 3.3.2 | When Using a Standard Power Supply Input (Single-phase |        |
|     |       | 100 V, Three-phase 200 V, or Three-phase 400 V)        | 3-22   |
|     | 3.3.3 | When Using the SERVOPACK with a Single-phase           |        |
|     |       | 200 V Power Input                                      | 3-27   |
|     | 3.3.4 | When Using the SERVOPACK with a DC Power Input         |        |
|     | 3.3.5 | When Using More Than One SERVOPACK                     | 3-34   |
|     | 226   | Conoral Propagations for Wiring                        | 2 25   |

|     | 3.3.7 Wiring the Spring Type Main Circuit Terminal Connector 3- | 36 |
|-----|---|----|
| 3.4 | Connecting Regenerative Resistors                               | 38 |
|     | 3.4.1 Connecting Regenerative Resistor                          | 38 |
|     | 3.4.2 Setting the Regenerative Resistor Capacity                | 41 |
| 3.5 | Linear Scale Connections3-4                                     | 42 |
|     | 3.5.1 Linear Scale Signal (CN2) Names and Functions3-           | 42 |
|     | 3.5.2 Linear Scale Connection Examples                          | 43 |
|     |   |    |

# **3.1** Precautions for Wiring

# **⚠** CAUTION

- Be sure to wire correctly and securely.
   Failure to observe this caution may result in motor overrun, injury, or malfunction.
- Do not bundle or run the main circuit cables together with the I/O signal cables or the linear scale connection cables in the same duct. Keep them separated by at least 30 cm.

Failure to do so may result in malfunction.


- Use shielded twisted-pair wires or multi-core shielded twisted-pair wires for I/O signal cables and the linear scale connection cables.
- The maximum cable length is 3 m for the I/O signals, 20 m for the linear servomotor main circuit, 20 m for serial converter unit, 15 m for the linear scale, 15 m for the hall sensor, and 10 m for control power supply cables for the SERVOPACK with a 400-V power supply (+24 V, 0 V).
- Do not touch the power terminals while the charge indicator is ON after turning power OFF because high voltage may still remain in the SERVOPACK.
   Make sure the charge indicator is off first before starting wiring and inspection.
- Leakage current may increase depending on the type of noise filter and the grounding conditions.
   When using a detector or a breaker for leakage current, select the appropriate one by considering the type of noise filter and the grounding conditions.
   For details, contact the manufacturer of the noise filter.
- Incorrect wiring or incorrect voltage application to the output circuit may cause short-circuit.
  - The above failures will prevent the holding brake from working, which may damage the machine or cause an accident resulting in death or injury.
- Inverting the polarity of the brake signal (/BK), i.e. positive logic, will prevent the
  holding brake from working in case of its signal line disconnection.
   If this setting is absolutely necessary, check the operation and confirm that there
  are no safety problems.

#### 

# **3.2** System Configuration Diagram


# **3.2.1** Connecting to SGDV-□□□□05□ SERVOPACK (Analog Pulse Model)

### (1) SGDV-□□□F05A



# (2) SGDV-□□□A05□ SERVOPACK


### ■ Using a Three-phase, 200-V Power Supply




#### 

# ■ Using a Single-phase, 200-V Power Supply

The  $\Sigma$ -V Series SERVOPACK for a 200-V power supply input has input specifications for a three-phase power supply, but some models can also be used with a single-phase 200-V power supply. For details, refer to  $\Sigma$ -V Series User's Manual Design and Maintenance Linear Motor/Analog Voltage and Pulse Train Reference (SIEP S800000 47).



# (3) SGDV-□□□D05A




- Use a 24 VDC power supply with double insulation or reinforced insulation. (The power supply is not included)
- \*2. Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.

#### 3.2.2 Connecting to SGDV-UUUU15U SERVOPACK (M-II Model)


# **3.2.2** Connecting to SGDV- SERVOPACK (M-II Model)

# (1) SGDV-□□□F15A



### (2) SGDV-□□□A15□


# ■ Using a Three-phase, 200-V Power Supply




#### 3.2.2 Connecting to SGDV-DDDD15D SERVOPACK (M-II Model)

# ■ Using a Single-phase, 200-V Power Supply

The  $\Sigma$ -V Series SERVOPACK for a 200-V power supply input has input specifications for a three-phase power supply, but some models can also be used with a single-phase 200-V power supply. For details, refer to  $\Sigma$ -V Series User's Manual Design and Maintenance Linear Motor/MECHATROLINK-II Communications Reference (SIEP S800000 48).



# (3) SGDV-□□□D15A




- Use a 24 VDC power supply with double insulation or reinforced insulation. (The power supply is not included)
- Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.

#### 3.2.3 Connecting to SGDV-DDDDD25D SERVOPACK (M-III Model)


# **3.2.3** Connecting to SGDV-□□□□25□ SERVOPACK (M-III Model)

# (1) SGDV-□□□F25A



#### (2) SGDV-□□□A25□


# ■ Using a Three-phase, 200-V Power Supply




#### 3.2.3 Connecting to SGDV-DDDDD25D SERVOPACK (M-III Model)

# ■ Using a Single-phase, 200-V Power Supply

The  $\Sigma$ -V Series SERVOPACK for a 200-V power supply input has input specifications for a three-phase power supply, but some models can also be used with a single-phase 200-V power supply. For details, refer to  $\Sigma$ -V Series User's Manual Design and Maintenance Linear Motor/MECHATROLINK-III Communications Reference (SIEP S800000 65).



# (3) SGDV-□□□D25A




- Use a 24 VDC power supply with double insulation or reinforced insulation. (The power supply is not included)
- Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.

3.2.4 Connecting to SGDV-DDDDE5A SERVOPACK (Command Option Attachable Type)

# **3.2.4** Connecting to SGDV-□□□□□E5A SERVOPACK (Command Option Attachable Type)


#### (1) SGDV-□□□FE5A



- \*1. Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.
- \*2. For connection to the command option module, refer to the user's manual of the corresponding option module.

# (2) SGDV-□□□AE5A

# ■ Using a Three-phase, 200-V Power Supply




- \*1. Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.
- \*2. For connection to the command option module, refer to the user's manual of the corresponding option module.

#### 3.2.4 Connecting to SGDV-DDDDE5A SERVOPACK (Command Option Attachable Type)


# ■ Using a Single-phase, 200-V Power Supply

The  $\Sigma$ -V Series SERVOPACK for a 200-V power supply input has input specifications for a three-phase power supply, but some models can also be used with a single-phase 200-V power supply. For details, refer to  $\Sigma$ -V Series User's Manual Design and Maintenance Linear Motor/Command Option Attachable Type (SIEP S800000 66).



- \*1. Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.
- \*2. For connection to the command option module, refer to the user's manual of the corresponding option module.

### (3) SGDV-□□□DE5A




- \*1. Use a 24-VDC power supply with double insulation or reinforced insulation. (The power supply is not included)
- Before connecting an external regenerative resistor to the SERVOPACK, refer to 3.4 Connecting Regenerative Resistors.
- \*3. For connection to the command option module, refer to the user's manual of the corresponding option module.


#### 3.3.1 Main Circuit Terminals


# 3.3 Main Circuit Wiring


The names and specifications of the main circuit terminals required for trial operation are given below.

# 3.3.1 Main Circuit Terminals









Analog Pulse Models

M-III Models

Command Option Attachable Types

| Terminal Symbols | Name                          | Model SGDV-□□□□                        | Description   |
|------------------|-------------------------------|--|---|
| L1, L2           |                               | □□□F                                   | Single-phase 100 to 115 V,<br>+10% to -15% (50/60 Hz) |
| L1, L2, L3       | Main circuit input terminals  | □□□А                                   | Three-phase 200 to 230 V,<br>+10% to -15% (50/60 Hz)  |
| 11, 12, 10       |                               | пппппппппппппппппппппппппппппппппппппп | Three-phase 380 to 480 V,<br>+10% to -15% (50/60 Hz)  |
| L1C. L2C         |                               | ОООF                                   | Single-phase 100 to 115 V,<br>+10% to -15% (50/60 Hz) |
| 210, 220         | Control power input terminals | □□□А                                   | Single-phase 200 to 230 V,<br>+10% to -15% (50/60 Hz) |
| 24 V, 0 V        |                               |  | 24 VDC, ±15%  |

# (cont'd)

| Terminal Symbols | Name   | Model SGDV-□□□□  | Description  |  |  |  |
|------------------|--|--|--|--|--|--|
|                  |  | R70F, R90F, 2R1F, 2R8F,<br>R70A, R90A, 1R6A,<br>2R8A                                     | If the regenerative capacity is insufficient, connect an external regenerative resistor (option) between B1/   and B2.   |  |  |  |
| B1/⊕, B2*1       | External<br>regenerative<br>resistor<br>terminals                                    | 3R8A, 5R5A, 7R6A,<br>120A, 180A, 200A,<br>330A, 1R9D, 3R5D,<br>5R4D, 8R4D, 120D,<br>170D | If the regenerative capacity is insufficient, remove the wire or short bar that shorts the connection between B2 and B3, and connect an external regenerative resistor (option) between B1/ $\oplus$ and B2. |  |  |  |
|                  |  | 550A, 260D   | Connect a regenerative resistor unit (option) between B1/ ⊕ and B2.  |  |  |  |
| ⊖1, ⊖2*²         | DC reactor<br>connection<br>terminals for<br>power supply<br>harmonic<br>suppression | □□□A<br>□□□D   | If a countermeasure against power supply harmonic waves is needed, connect a DC reactor between ⊖ 1 and ⊖ 2.   |  |  |  |
| B1/⊕             | Main circuit plus terminals  | □□□A<br>□□□D   | Use when DC power supply input is  |  |  |  |
| ⊖ 2 or ⊝         | Main circuit minus terminals   |  | used.  |  |  |  |
| U, V, W          | Linear<br>servomotor<br>connection<br>terminals                                      | Use for connecting to the l  | inear servomotor.  |  |  |  |
|                  | Ground<br>terminals<br>(× 2)   | Use for connecting the power supply ground terminal and lin servomotor ground terminal.  |  |  |  |  |

 <sup>\*1.</sup> Do not open short-circuit B1/ ⊕ and B2 terminals. Doing so may damage the SERVO-PACK.

<sup>\*2.</sup> The  $\bigcirc$  1 and  $\bigcirc$  2 is short-circuited with a jumper at the factory.

 $3.3.2\,$  When Using a Standard Power Supply Input (Single-phase 100 V, Three-phase 200 V, or Three-phase 400 V)

# **3.3.2** When Using a Standard Power Supply Input (Single-phase 100 V, Three-phase 200 V, or Three-phase 400 V)

# (1) Wire Types

Use the following type of wire for main circuit.

|        | Cable Type   | Allowable Conductor |
|--------|--|---------------------|
| Symbol | Name   | Temperature (°C)    |
| IV     | 600 V polyvinyl chloride insulated wire                      | 60                  |
| HIV    | 600 V grade heat-resistant polyvinyl chloride insulated wire | 75                  |

The following table shows the wire sizes and allowable currents for three wires. Use wires with specifications equal to or less than those shown in the table.

#### 600 V grade heat-resistant polyvinyl chloride insulated wire (HIV)

| AWG<br>Size | Nominal<br>Cross<br>Section<br>Diameter | Configuration (Number of | (Number of Resistance |      | Allowable Current at<br>Surrounding Air Temperature<br>(A) |      |  |  |
|-------------|---|--------------------------|-----------------------|------|--|------|--|--|
|             | (mm <sup>2</sup> )                      | Wires/mm <sup>2</sup> )  | (Ω/km)                | 30°C | 40°C   | 50°C |  |  |
| 20          | 0.5                                     | 19/0.18                  | 39.5                  | 6.6  | 5.6  | 4.5  |  |  |
| 19          | 0.75                                    | 30/0.18                  | 26.0                  | 8.8  | 7.0  | 5.5  |  |  |
| 18          | 0.9                                     | 37/0.18                  | 24.4                  | 9.0  | 7.7  | 6.0  |  |  |
| 16          | 1.25                                    | 50/0.18                  | 15.6                  | 12.0 | 11.0   | 8.5  |  |  |
| 14          | 2.0                                     | 7/0.6                    | 9.53                  | 23   | 20   | 16   |  |  |
| 12          | 3.5                                     | 7/0.8                    | 5.41                  | 33   | 29   | 24   |  |  |
| 10          | 5.5                                     | 7/1.0                    | 3.47                  | 43   | 38   | 31   |  |  |
| 8           | 8.0                                     | 7/1.2                    | 2.41                  | 55   | 49   | 40   |  |  |
| 6           | 14.0                                    | 7/1.6                    | 1.35                  | 79   | 70   | 57   |  |  |
| 4           | 22.0                                    | 7/2.0                    | 0.85                  | 91   | 81   | 66   |  |  |

Note: The values in the table are for reference only.

# (2) SERVOPACK Main Circuit Wires

The wires used in the SERVOPACK main circuit are described below.



- Wire sizes are selected for three cables per bundle at 40°C surrounding air temperature with the rated current.
- Use a wire with a minimum withstand voltage of 600 V for the main circuit.
- If cables are bundled in PVC or metal ducts, take into account the reduction of the allowable current.
- Use a heat-resistant wire under high surrounding air or panel temperatures, where polyvinyl chloride insulated wires will rapidly deteriorate.

# ■ Single-phase, 100 V

| Terminal | Terminal Names                                      | SERVOPACK Model SGDV-□□□F |        |           |      |  |  |
|----------|---|---------------------------|--------|-----------|------|--|--|
| Symbols  | Terrifical rearries                                 | R70 R90                   |        | 2R1       | 2R8  |  |  |
| L1, L2   | Main circuit power input terminals                  | HIV                       | 1.25   | HIV       | 72.0 |  |  |
| L1C, L2C | Control power input terminals HIV1.25               |                           |        |           |      |  |  |
| U, V, W  | Linear servomotor connection terminals              |                           | HIV    | 1.25      |      |  |  |
| B1/⊕, B2 | External regenerative resistor connection terminals |                           |        |           |      |  |  |
|          | Ground terminal                                     |                           | HIV2.0 | or higher |      |  |  |

# ■ Three-phase, 200 V

| Terminal      | Terminal Names                                      | SERVOPACK Model SGDV-□□□A |         |     |              |     | SERVOPACK Model SGDV-□□□A |      |            |            |            |             |             |  |
|---------------|---|---------------------------|---------|-----|--------------|-----|---------------------------|------|------------|------------|------------|-------------|-------------|--|
| Symbols       | Terrilliai Names                                    | R70                       | R90     | 1R6 | 2R8          | 3R8 | 5R5                       | 7R6  | 120        | 180        | 200        | 330         | 550         |  |
| L1, L2,<br>L3 | Main circuit power input terminals                  | HIV1.25                   |         |     | V1.25 HIV2.0 |     |                           |      | HIV        | /3.5       | HIV<br>5.5 | HIV<br>14.0 |             |  |
| L1C,<br>L2C   | Control power input terminals                       |                           | HIV1.25 |     |              |     |                           |      |            |            |            |             |             |  |
| U, V, W       | Linear<br>servomotor<br>connection<br>terminals     | HIV1.25                   |         |     |              |     | HIV                       | /2.0 |            | HIV<br>3.5 | HIV<br>5.5 | HIV<br>8.0  | HIV<br>14.0 |  |
| B1/⊕,<br>B2   | External regenerative resistor connection terminals | HIV1.25                   |         |     |              |     |                           |      | HIV<br>2.0 | HIV<br>3.5 | HIV<br>5.5 | HIV<br>8.0  |             |  |
|               | Ground terminal                                     | HIV2.0 or higher          |         |     |              |     |                           |      |            |            |            |             |             |  |

3.3.2 When Using a Standard Power Supply Input (Single-phase 100 V, Three-phase 200 V, or Three-phase 400 V)


# ■ Three-phase, 400 V

| Terminal   | Terminal Names                             | SERVOPACK Model SGDV-□□□D |         |     |     |      |        |            |
|------------|--|---------------------------|---------|-----|-----|------|--------|------------|
| Symbols    | Terrinia Names                             | 1R9                       | 3R5     | 5R4 | 8R4 | 120  | 170    | 260        |
| L1, L2, L3 | Main circuit power input terminals         |                           | HIV1.25 |     | HIV | 72.0 | HIV3.5 | HIV<br>5.5 |
| 24 V, 0 V  | Control power input terminals              |                           |         |     |     |      |        |            |
| U, V, W    | Linear servomotor connection terminals     | HIV1.25                   |         |     | HIV | 72.0 | HIV3.5 | HIV5.5     |
| B1/⊕, B2   | External regenerative connection terminals | HIV1.25                   |         |     |     |      | HIV2.0 | HIV3.5     |
|            | Ground terminal                            | HIV2.0 or higher          |         |     |     |      |        |            |

# (3) Typical Main Circuit Wiring Examples


The following wiring examples show the  $\Sigma$ -V Series SGDV SERVOPACK (Analog pulse model).

# ■ Single-phase 100 V, SGDV-□□□F (SGDV-R70F, R90F, 2R1F, 2R8F)



Note: For M-II model, M-III model, and command option attachable type SERVOPACKs, the pin number of ALM+ terminal is CN1-3, and that of ALM- terminal is CN1-4.


# ■ Three-phase 200 V, SGDV-□□□A (SGDV-R70A, R90A, 1R6A, 2R8A, 3R8A, 5R5A, 7R6A, 120A, 180A, 200A, 330A)



<sup>\*</sup> For SGDV-R70A, R90A, 1R6A, and 2R8A SERVOPACKs, the short-circuit between B2 and B3 is not required. Do not short the connection between B2 and B3.


Note: For M-II model, M-III model, and command option attachable type SERVOPACKs, the pin number of ALM+ terminal is CN1-3, and that of ALM- terminal is CN1-4.

#### ■ Three-phase 200 V, SGDV-□□□A (SGDV-550A))




3.3.2 When Using a Standard Power Supply Input (Single-phase 100 V, Three-phase 200 V, or Three-phase 400 V)

# ■ Three-phase 400 V, SGDV-□□□D (SGDV-1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D)



Note: For M-II model, M-III model, and command option attachable type SERVOPACKs, the pin number of ALM+ terminal is CN1-3, and that of ALM- terminal is CN1-4.

#### ■ Three-phase 400 V, SGDV-□□□D (SGDV-260D)



# **3.3.3** When Using the SERVOPACK with a Single-phase 200 V Power Input

Some models of  $\Sigma$ -V series three-phase 200 V power input SERVOPACK can be used also with a single-phase 200 V power supply.

The following models support single-phase 200 V power input. SGDV-R70A, -R90A, -1R6A, -2R8A, -5R5A

When using the SERVOPACK with single-phase, 200 V power input, set parameter Pn00B.2 to 1.

#### (1) Parameter Setting

#### ■ Single-phase Power Input Selection

| Parameter |   | Meaning   | When<br>Enabled | Classifica<br>tion |
|-----------|---|---|-----------------|--------------------|
| Pn00B     | n.□□□□ Enables use of three-phase power ply for three-phase SERVOPACK |   | After restart   | Setup              |
|           | n.□1□□  | Enables use of single-phase power supply for three-phase SERVOPACK. |                 |                    |

## **M** WARNING

- If a single-phase 200 V is input to a single-phase 200 V power input supported SERVOPACK without having changed the setting of Pn00B.2 to 1 (single-phase power input), the main circuit cable open phase alarm (A.F10) will be detected.
- If a single-phase 200 V is input to the SERVOPACK models that do not support single-phase power input, the main circuit cable open phase alarm (A.F10) will be detected.
- When using a single-phase 200 V power supply, the SERVOPACK may not be able to produce the same linear servomotor force-speed characteristics as using a three-phase 200 V power input. Refer to the diagram of each motor force-speed characteristics in Σ-V Series Product Catalog (KAEPS80000042).

#### 3.3.3 When Using the SERVOPACK with a Single-phase 200 V Power Input

### (2) Main Circuit Power Input

Connect a single-phase 200 V power supply of the following specifications to L1 and L2 terminals. The specifications of the power supplies other than the main circuit power supply are the same as for three-phase power supply input.


| Terminal<br>Symbols | Terminal Name                      | Model<br>SGDV-□□□A         | Ratings  |
|---------------------|------------------------------------|----------------------------|--|
| L1, L2              | Main circuit power input terminals | R70, R90, 1R6,<br>2R8, 5R5 | Single-phase 200 V to 230 V,<br>+10% to -15% (50/60Hz) |
| L3 <sup>*</sup>     | _                                  | 200, 303                   | None   |

<sup>\*</sup> Do not use L3 terminal.

### (3) SERVOPACK Main Circuit Wires

| Terminal Names   |  | 形式 SGDV-□□□A |                 |             |      |     |
|--|--|--------------|-----------------|-------------|------|-----|
| Symbols  | Terminal Names                           | R70          | R90             | 1R6         | 2R8  | 5R5 |
| L1, L2   | Main circuit power input terminals       | HIV1.25 HIV2 |                 | IV2.0       |      |     |
| L1C, L2C   | Control power input terminals            | HIV1.25      |                 |             |      |     |
| U, V, W  | W Linear servomotor connection terminals |              | HIV1.25 HIV 2.0 |             |      |     |
| B1/   B2 External regenerative resistor connection terminals |  | HIV1.25      |                 |             |      |     |
|  | Ground terminal                          |              | HIV             | 72.0 or his | gher |     |

- (4) Wiring Example with a Single-phase 200 V Power Supply Input The following wiring example shows the Σ-V series SGDV SERVOPACK (Analog pulse model).
  - Single-phase 200 V Power Input Supported SERVOPACK Models SGDV-R70A, -R90A, -1R6A, -2R8A, and -5R5A



#### 3.3.4 When Using the SERVOPACK with a DC Power Input

## **3.3.4** When Using the SERVOPACK with a DC Power Input

#### (1) Parameter Setting

When using the SERVOPACK with a DC power input, make sure to set the parameter Pn001.2 to 1 before inputting DC power.

| Parameter Meaning |        | When<br>Enabled                | Classifica<br>tion |       |
|-------------------|--------|--------------------------------|--------------------|-------|
| Pn001             | n.□0□□ | Enables use of AC power input. | After restart      | Setup |
| 1 11001           | n.□1□□ | Enables use of DC power input. | 7 Hich restair     | Setup |

Observe the following warnings.

## **M** WARNING

- Either AC or DC power can be input to the 200 V and 400 V SERVOPACKs. Always set Pn001.2 to 1 to specify a DC power input before inputting DC power. Only AC power can be input to the 100 V SERVOPACKs.
   If DC power is input without changing the parameter setting, the SERVOPACK's internal elements will burn and may cause fire or equipment damage.
- With a DC power input, time is required to discharge electricity after the main power supply is turned OFF. A high residual voltage may remain in the SERVO-PACK after the power supply is turned OFF. Be careful not to get an electric shock.
- · Install fuses on the wires if DC power is used.
- Linear servomotor returns a regenerated energy to the power supply. The SER-VOPACK that can use a DC power supply is not capable of processing the regenerated energy. Provide measures to process the regenerated energy on the power supply.
- With a DC power input, connect an external inrush current limit circuit.
   Failure to observe this caution may result in damage to the product.

- (2) DC Power Supply Input Terminals for the Main and Control Circuits
  - Three-phase, 200 V SGDV-□□□A (□□□ = R70, R90, 1R6, 2R8, 3R8, 5R5, 7R6, 120, 180, 200, 330)

| Terminal Symbols | inal Symbols Terminal Names   |                |
|------------------|-------------------------------|----------------|
| B1/⊕, B2         | Main circuit plus terminals   | 270 to 320 VDC |
| ⊖ 2              | Main circuit minus terminal   | 0 VDC          |
| L1C, L2C         | Control power input terminals | 200 to 230 VAC |

■ Three-phase, 200 V SGDV-□□□A (□□□ = 550)

| Terminal Symbols | Terminal Names                | Specifications |
|------------------|-------------------------------|----------------|
| B1/⊕, B2         | Main circuit plus terminals   | 270 to 320VDC  |
| ⊖ 2              | Main circuit minus terminal   | 0 VDC          |
| L1C, L2C         | Control power input terminals | 200 to 230VAC  |

■ Three-phase, 400 V SGDV-□□□D (□□□ = 1R9, 3R5, 5R4, 8R4, 120, 170, 260)


| Terminal Symbols | Terminal Names                | Specifications |
|------------------|-------------------------------|----------------|
| B1/⊕, B2         | Main circuit plus terminals   | 513 to 648VDC  |
| ⊖ 2              | Main circuit minus terminal   | 0 VDC          |
| L1C, L2C         | Control power input terminals | 24 VDC ±15%    |

#### 3.3.4 When Using the SERVOPACK with a DC Power Input


## (3) Wiring Examples with a DC Power Input

The following examples show the  $\Sigma$ -V series SGDV SERVOPACK (Analog pulse model).

#### ■ Three-phase, 200 V SGDV-□□□A



### ■ Three-phase, 400 V SGDV-□□□D



\* The terminal names differ depending on the SERVOPACK model. Refer to (2) Main Circuit and Control Power Inputs.

#### 3.3.5 When Using More Than One SERVOPACK

## 3.3.5 When Using More Than One SERVOPACK


This section shows an example of the wiring when more than one SERVOPACK is used and the precautions.

#### ■ Wiring Example (Analog pulse model)

The following example shows the  $\Sigma$ -V series SGDV SERVOPACK (Analog pulse model).

Connect the alarm output (ALM) terminals for the three SERVOPACKs in series to enable alarm detection relay 1RY to operate.

When the alarm occurs, the ALM output signal transistor is turned OFF.



## **3.3.6** General Precautions for Wiring



IMPORTANT

 Use a molded-case circuit breaker (1QF) or fuse to protect the main circuit.

The SERVOPACK connects directly to a commercial power supply; it is not isolated through a transformer or other device. Always use a molded-case circuit breaker (1QF) or fuse to protect the servo system from accidents involving different power system voltages or other accidents.

- Install a ground fault detector.
   The SERVOPACK does not have a built-in protective circuit for grounding. To configure a safer system, install a ground fault detector against overloads and short-circuiting, or install a ground fault detector in combination with a molded-case circuit breaker.
- · Do not frequently turn power ON and OFF.
  - Frequently turning power ON and OFF will causes elements inside the SERVOPACK to deteriorate. Do not use the servo drives for an application that requires frequently turning ON and OFF the power supply.
  - After the actual operation starts, the allowable interval for turning ON and OFF is one hour or longer.

To ensure safe, stable application of the servo system, observe the following precautions when wiring.

Use the connecting cables specified in the  $\Sigma$ -V Series Product Catalog (KAEP S800000 42). Design and arrange the system so that each cable will be as short as possible.

- Use shielded twisted-pair wires or shielded multi-core twisted-pair wires for I/O signal cables and the linear scale connection cables.
- The maximum cable length is 3 m max. for I/O signal cables, 20 m max. for linear servomotor main circuit, 20 m for the serial converter unit, 15 m for the linear scale, and 15 m for the hall sensor.

Observe the following precautions when wiring the ground.

- Use a cable as thick as possible (at least 2.0 mm<sup>2</sup>)
- Grounding to a resistance of 100  $\Omega$  or less for 100-V, 200-V SERVOPACKs, 10  $\Omega$  or less for 400-V SERVOPACK is recommended.
- Be sure to ground at only one point.
- Ground the linear servomotor directly if the linear servomotor is insulated from the machine.

The signal cable conductors are as thin as  $0.2~\text{mm}^2$  or  $0.3~\text{mm}^2$ . Do not impose excessive bending force or tension.

#### 3.3.7 Wiring the Spring Type Main Circuit Terminal Connector

## **3.3.7** Wiring the Spring Type Main Circuit Terminal Connector

Two types of main circuit terminals are available: a connector type and a terminal screw type.

- SERVOPACKs with terminal screws: SGDV-180A, 200A, 330A, 550A, 8R4D, 120D, 170D, 260D
- SERVOPACKs with connectors:
   SGDV-R70F, R90F, 2R1F, 2R8F, R70A, R90A, 1R6A, 2R8A, 3R8A, 5R5A, 7R6A, 120A, 1R9D, 3R5D, 5R4D

A spring connector is used for SERVOPACKs with connectors.


The following section describes how to wire the main circuit terminal using a connector.

## **↑** CAUTION


- Observe the following precautions when wiring main circuit terminal connectors.
  - For the SERVOPACK's with connectors, remove detachable main circuit terminal connectors from the SERVOPACK prior to wiring.
  - Insert only one main circuit cable per opening in the main circuit terminal connector.
  - Make sure that no part of the core wire comes into contact with (i.e., short-circuit) adjacent wires.

## ■ Wiring Procedure

**1.** Remove the main circuit terminal connector from the SERVOPACK.




#### 2. Strip the end of the wires.



- **3.** Open the wire terminal on the terminal connector housing with a tool, using the following methods. Either method can be used to open the wire terminal.
- Using a spring opener


Use the spring opener provided with the SERVOPACK to open the wire terminal as shown in the diagram.

Note: The spring opener (1981045-1) made by Tyco Electronics AMP K.K. can also be used.



#### · Using a screwdriver

Use a commercially available flat-blade screwdriver with a blade width of 3.0 to 3.5 mm. Insert the screwdriver into the slot and press down firmly to open the wire terminal.



- **4.** Insert the wire core into the opening, and then secure the wire into position by removing the opener or screwdriver to close the opening.
- **5.** Make all the required connections in the same way.
- **6.** Attach the connector to the SERVOPACK.

#### 3.4.1 Connecting Regenerative Resistor

## **3.4** Connecting Regenerative Resistors

If the capacity to absorb regenerative energy is insufficient, use the following procedure to connect an external regenerative resistor and set the regenerative resistor capacity in the parameter Pn600.

To learn how to select a regenerative resistor, and for detailed specifications, refer to  $\Sigma$ -V Series Product Catalog (KAEP S800000 42).

#### *∧* WARNING


 Be sure to connect the regenerative resistor correctly. Do not short-circuit between B1/⊕ and B2.
 Failure to observe this warning may result in fire or damage to the regenerative resistor or SERVOPACK.

#### **3.4.1** Connecting Regenerative Resistor

This section describes how to connect a regenerative resistor.

## (1) SERVOPACKs: Model SGDV-R70F, R90F, 2R1F, 2R8F, R70A, R90A, 1R6A, or 2R8A


Connect an external regenerative resistor between  $B1/\oplus$  and B2 terminals. After connecting a resistor, set the regenerative resistor capacity. Refer to 3.4.2 Setting the Regenerative Resistor Capacity for information on how to set the regenerative resistor capacity.



## (2) SERVOPACKs: Model SGDV-3R8A, 5R5A, 7R6A, 120A, 180A, 200A, 330A, 1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D

Disconnect the wiring between the SERVOPACK's B2 and B3 terminals and connect an external regenerative resistor between the B1/ $\oplus$  and B2 terminals. After connecting a resistor, set the regenerative resistor capacity. Refer to 3.4.2 Setting the Regenerative Resistor Capacity for information on how to set the regenerative resistor capacity.

Note: Be sure to take out the lead wire between the B2 and B3 terminals.



#### (3) SERVOPACKs: Model SGDV-550A, 260D

No built-in regenerative resistor is provided, so the external regenerative resistor is required. The following regenerative resistor units are available as option:


Note: The regenerative resistor unit is constructed from a number of resistors.

| Main<br>Circuit<br>Power<br>Supply | SERVOPACK<br>Model SGDV- | Applicable<br>Regenerative<br>Resistor Unit | Resistance $(\Omega)$ | Specifications  |
|------------------------------------|--------------------------|---|-----------------------|---|
| Three-<br>phase<br>200 V           | 550A                     | JUSP-RA05-E                                 | 3.13                  | Eight 25 $\Omega$ (220 W) resistors are connected in parallel.                  |
| Three-<br>phase<br>400 V           | 260D                     | JUSP-RA18-E                                 | 18                    | Two series of two 18 $\Omega$ (220 W) resistors each are connected in parallel. |

Connect a regenerative resistor unit between B1/⊕ and B2 terminals.

#### 3.4.1 Connecting Regenerative Resistor

When using one of the aforementioned regenerative resistor units, set Pn600 to 0W (factory setting). If using any other regenerative resistor, set Pn600 to the capacity of the connected regenerative resistor.



## **3.4.2** Setting the Regenerative Resistor Capacity

When an external regenerative resistor is connected, make sure to set the regenerative resistor capacity using the parameter Pn600.

#### **MARNING**

If 0 is set to the parameter Pn600 while an external regenerative resistor is connected, the generative overload alarm (A.320) may not be detected. If the generative overload alarm (A.320) is not detected correctly, the external regenerative resistor may be damaged and an injury or fire may result. Be sure to set the parameter Pn600 to the capacity of the connected external regenerative resistor.

|       | Regenerative Resi       | stor Capacity |                    | Speed        | Position Force |
|-------|-------------------------|---------------|--------------------|--------------|----------------|
| Pn600 | Setting Range           | Unit          | Factory<br>Setting | When Enabled | Classification |
|       | 0 to SERVOPACK capacity | 10 W          | 0                  | Immediately  | Setup          |

Be sure to set this parameter when installing an external regenerative resistor to the SERVOPACK. Set the regenerative resistor capacity within tolerance value. The set value differs depending on the cooling method of external regenerative resistor:

- For natural air cooling method: Set the value maximum 20% of the actually installed regenerative resistor capacity (W).
- For forced air cooling method: Set the value maximum 50% of the actually installed regenerative resistor capacity (W).

(Example)100 W external regenerative resistor with natural cooling method  $100 \text{ W} \times 20\% = 20 \text{ W}$ , therefore, Pn600 = 2 (units: 10 W)

- Note: 1. When the set value is improper, the generative overload alarm (A.320) is detected.
  - The factory setting of "0" is the value when the SERVOPACK's built-in regenerative resistor is used.



- When the external regenerative resistors for power are used at the rated load ratio, the resistor temperature increases to between 200 °C and 300 °C. The resistors must be used at or below the rated values. Check with the manufacturer for the resistor's load characteristics.
- For safety, use the external resistors with thermoswitches.

3.5.1 Linear Scale Signal (CN2) Names and Functions

## **3.5** Linear Scale Connections

This section describes connection examples between linear scale and SERVOPACK, and the terminal layout of the connector CN2 for connecting a linear scale.

## **3.5.1** Linear Scale Signal (CN2) Names and Functions

The following table shows the names and functions of the linear scale signals (CN2).


| Signal Name | Pin Number | Function                       |
|-------------|------------|--------------------------------|
| PG 5 V      | 1          | Linear scale power supply +5 V |
| PG 0 V      | 2          | Linear scale power supply 0 V  |
| _           | 3*         | -                              |
| _           | 4*         | -                              |
| PS          | 5          | Serial data (+)                |
| /PS         | 6          | Serial data (-)                |
| Shield      | Shell      | -                              |

<sup>\*</sup> The pins 3 and 4 are connected to the internal circuit. Do not use them.

## 3.5.2 Linear Scale Connection Examples


The following diagrams show linear scale connection examples.

#### (1) Linear Scale Made by Heidenhain



\* represents shielded twisted-pair wires.


## (2) Linear Scale Made by Renishaw



\* represents shielded twisted-pair wires.


#### 3.5.2 Linear Scale Connection Examples

#### (3) Linear Scale Made by Mitutoyo



- \* represents shielded twisted-pair wires.
- (4) Linear Scale Made by Magnescale Co., Ltd.


#### ■ SR75, SR85, SR77, SR87



\* represents shielded twisted-pair wires.

3-44

### ■ SL700, SL710, SL720, SL730



\* represents shielded twisted-pair wires.

3.5.2 Linear Scale Connection Examples

## Safety Function

This chapter describes the safety functions.

| 4.1 | Outline  | 2  |
|-----|--|----|
| 4.2 | Hard Wire Base Block (HWBB) Function 4             | -3 |
| 4.3 | Safety Function Signal (CN8) Names and Functions 4 | -4 |
| 4.4 | Precautions When Not Using the Safety Function 4   | -4 |
| 4.5 | Connecting a Safety Function Device 4              | -5 |

### **4.1** Outline


The safety function is incorporated in the SERVOPACK to reduce the risk associated with the machine by protecting workers from injury and by securing safe machine operation. Especially when working in hazardous areas inside the safeguard, as for machine maintenance, it can be used to avoid adverse machine movement.

The person who designs a system using the safety function (Hard Wire Base Block function) must have full knowledge of the related safety standards and full understanding of the following manuals.

- Σ-V Series User's Manual Design and Maintenance Linear Motor/Analog Voltage and Pulse Train Reference (SIEP S800000 47)
- Σ-V Series User's Manual Design and Maintenance Linear Motor/MECHATROLINK-II Communications Reference (SIEP S800000 48)
- Σ-V Series User's Manual Design and Maintenance Linear Motor/MECHATROLINK-III Communications Reference (SIEP S800000 65)
- Σ-V Series User's Manual Design and Maintenance Linear Motor/Command Option Attachable Type (SIEP S800000 66)

## 4.2 Hard Wire Base Block (HWBB) Function

The Hard Wire Base Block function (hereinafter referred to as HWBB function) is a safety function designed to baseblock the motor (shut off the motor current) by using the hardwired circuits: Each circuit for two channel input signals blocks the run signal to turn off the power module, and the motor current is shut off. (Refer to the diagram below.)



ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

## *∧* WARNING

 Perform risk assessment for the system and confirm that the safety requirements with the following standards are fulfilled before using the HWBB function. EN954-1 Category3 IEC61508-1 to 4 SIL2

## **4.3** Safety Function Signal (CN8) Names and Functions

The following table shows the terminal layout of safety function signals (CN8).

| Pin No. | Signal<br>Name | Function                          |  |  |
|---------|----------------|-----------------------------------|--|--|
| 1*      | -              | -                                 |  |  |
| 2*      | -              | -                                 |  |  |
| 3       | /HWBB1-        | Hard wire baseblock input 1       |  |  |
| 4       | /HWBB1+        | That'd wife baseblock input 1     | Hard wire baseblock input<br>Baseblock (motor current off)<br>when OFF |  |
| 5       | /HWBB2-        | Hard wire baseblock input 2       |  |  |
| 6       | /HWBB2+        | That wife baseofoek input 2       |  |  |
| 7       | EDM1-          |                                   | ON when the /HWBB1 and the /HWBB2 signals are input and                |  |
| 8       | EDM1+          | Monitored circuit status output 1 | the SERVOPACK enters a baseblock state.                                |  |

<sup>\*</sup> The pins 1 and 2 are connected to the internal circuit. Do not use them.


## **4.4** Precautions When Not Using the Safety Function

When not using the safety function or when performing a JOG operation, use the SERVOPACK with the safety function jumper connector (JZSP-CVH05-E, provided as an accessory) inserted. If the SERVOPACK is used without the jumper connector inserted into CN8, no current will flow to the motor and no motor force will be output.

When Hbb is displayed on the panel operator and digital operator, the motor is base-blocked by the safety function. Check to see if the JZSP-CVH05-E jumper connector is correctly inserted into CN8.

## 4.5 Connecting a Safety Function Device

There are the following two types of safety function's jumper connectors that are provided with the SERVOPACKs. The safety function's jumper connector must be removed to attach a safety function device. Read the following procedure carefully and then attach the safety function device.




Connect a safety function device using the following procedure.

 Remove the servomotor connection terminal connector while pressing the lock.

Applicable SERVOPACKs:


SGDV-R70F, -R90F, -2R1F, -R70A, -R90A, -1R6A, -2R8A, -1R9D, -3R5D, -5R4D

For SERVOPACK models not listed above, it is not necessary to remove the servomotor connection terminal connector. Go to step 2.



## 2. <Using previous model>


Slide the lock injector of the safety function's jumper connector to the SERVOPACK side to unlock and remove the safety function's jumper connector.



Note:The safety function's jumper connector may be damaged if removed while the lock is still on.

#### <Using new model>

Remove the safety function's jumper connector from CN8.



## 3. Connect a safety function device to CN8.

Note: When not using the safety function, use the SERVOPACK with the safety function's jumper connector (JZSP-CVH05-E provided as an accessory) inserted in CN8. If the SERVOPACK is used without the jumper connector inserted into CN8, no current will flow to the servomotor and no torque will be output. In this case, "Hbb" will be displayed on the digital operator.

## Trial Operation (Checking Linear Servomotor Operation)

This chapter describes how to perform trial operation.

| Outline   | 5-2                              |
|---|----------------------------------|
| Inspection and Checking before Trial Operation  | 5-3                              |
| Setting the SERVOPACK Parameters  5.3.1 Setting and Checking the Linear Scale Pitch  5.3.2 Hall Sensor Selection  5.3.3 Motor Phase Selection  5.3.4 Setting the Overtravel Signals  5.3.5 Setting the Force Limits             | . 5-4<br>. 5-9<br>. 5-9<br>5-11  |
| o.o.o Cetting the Force Limits  | 0 11                             |
| Execution of Origin Setting (Fn020)   | 5-12                             |
| Execution of Origin Setting (Fn020)  Polarity Detection  5.5.1 When Using an Incremental Linear Scale  5.5.2 When Using an Absolute Linear Scale  5.5.3 Troubleshooting for Polarity Detection Errors  5.5.4 Related Parameters | 5-15<br>5-16<br>5-18<br>5-21     |
|   | Setting the SERVOPACK Parameters |

#### **5.1** Outline

The trial operation described here is a JOG operation for linear servomotors not connected to machinery (without a load). The purpose of this trial operation is to check whether the SERVOPACK and linear servomotor are properly connected and whether the linear servomotor is operating correctly.

To conduct trial operation executed from the host controller for the linear servomotor without a load, or for the linear servomotor connected to the machine, refer to the following manuals.

- Σ-V Series User's Manual Design and Maintenance Linear Motor/Analog Voltage and Pulse Train Reference (SIEP S800000 47)
- Σ-V Series User's Manual Design and Maintenance Linear Motor/MECHATRO-LINK-II Communications Reference (SIEP S800000 48)
- Σ-V Series User's Manual Design and Maintenance Linear Motor/MECHATRO-LINK-III Communications Reference (SIEP S800000 65)
- $\Sigma$ -V Series User's Manual Design and Maintenance Linear Motor/Command Option Attachable Type (SIEP S800000 66)

## **⚠** CAUTION

 Before conducting trial operation, always make sure that an emergency stop can be immediately executed.

## **5.2** Inspection and Checking before Trial Operation

To ensure safe and correct trial operation, inspect and check the following items before starting trial operation.

#### (1) Linear Servomotors

Inspect and check the following items, and take appropriate measures before performing trial operation if any problem exists.

- Are all wiring and connections correct?
- Are all nuts and bolts securely tightened?

#### (2) SERVOPACKs


Inspect and check the following items, and take appropriate measures before performing trial operation if any problem exists.

- · Are all installation, wiring and connections correct?
- Is the correct power supply voltage being supplied to the SERVOPACK?

## (3) Checking the Main Circuit Power Supply, Linear Servomotor, and Linear Scale Wirings

Once again, check the main circuit power supply, linear servomotor, and linear scale wiring that was described in *Chapter 3 Wiring and Connection*.

Perform a trial operation with the safety function jumper connector (JZSP-CVH05-E,



Make sure that the following cables are correctly connected.

- · Main circuit cable
- · Linear servomotor main circuit cable
- Cable for connecting the serial converter unit
- Cable for connecting the linear scale
- Cable for connecting the hall sensor

#### 5.3.1 Setting and Checking the Linear Scale Pitch

## **5.3** Setting the SERVOPACK Parameters

Set the following SERVOPACK parameters.

- Linear scale pitch (Pn282)
- Hall sensor selection (Pn080.0)
- Motor phase selection (Pn080.1)
- Overtravel signal mapping (Pn50A.3, Pn50B.0)
- Force limit (Pn483, Pn484)

## **5.3.1** Setting and Checking the Linear Scale Pitch

#### (1) When Using a Serial Converter Unit

Turn ON the control power supply.

When the power is supplied normally, the panel operator on the front panel of the SERVOPACK will show the following display. A linear scale pitch setting error (A.080) will be displayed, but does not indicate an error. Set the linear scale pitch (Pn282) according to the scale being used. After setting validation of the control power, the A.080 alarm will be cleared, and the settings will be enabled.



If an alarm other than A.080 is displayed, as shown in the following diagram, the wiring for the power supply circuit, the linear servomotor main circuit cable or the cable for connecting the serial converter unit is the probable cause. Shut down the power supply, specify the location causing the alarm, and take corrective measures so that the display returns to the above normal status. For details on alarms, refer to the corresponding SERVOPACK or command option module user's manual (see  $\blacksquare$  Manuals Related to the  $\Sigma$ -V Series in About this Manual.)




|       | Linear Scale Pitch |              | Speed Position Force |               |
|-------|--------------------|--------------|----------------------|---------------|
| Pn282 | Setting Range      | Setting Unit | Factory Setting      | When Enabled  |
|       | 0 to 6553600       | 0.01 μm      | 0                    | After restart |

If the linear scale pitch (Pn282) is not set correctly, the linear servomotor cannot be controlled. Make sure that the correct value is set before operating the linear servomotor.

When using a SERVOPACK right after factory shipment, the alarm A.080 (Linear Scale Pitch Setting Error) will be displayed but does not indicate an error. This alarm is generated to remind the user to set Pn282. Set Pn282 to a correct value and turn OFF the power then ON again. The alarm A.080 will be cleared.

When using a serial converter unit model JZDP-D00 \(\subseteq \subseteq \subseteq \text{LDP-D00}\), the SERVOPACK uses 1/256 the distance of the scale pitch as a minimum feedback pulse. (The count is performed in the serial converter unit using 1/256 of the linear scale pitch.)




#### (2) When Not Using a Serial Converter Unit

When not using a serial converter unit (when connecting a linear scale directly to the SERVOPACK), the motor parameters must be written into the linear scale via the SERVOPACK using the SigmaWin+ software engineering tool.

## **M** WARNING

Before writing the parameters, check the motor and linear scale data.
 Writing incorrect parameters may cause motor overrun or burnout, resulting in damage to the product or fire.



#### 5.3.1 Setting and Checking the Linear Scale Pitch

#### ■ Setup Procedure

- 1. Prepare the motor parameters to be written into the linear scale and the SigmaWin+ software version 3.01 or later.
- 2. Install SigmaWin+ in a personal computer.
- **3.** Use a standard USB cable to connect the personal computer to the SERVOPACK CN3 port.

Start SigmaWin+ to write the motor parameters into the linear scale via the SERVOPACK.

(Refer to SigmaWin+ Operation Manual for information on how to write parameters using SigmaWin+.)



Note that no motor parameters contain the serial number data.
 Serial numbers cannot be checked by using the SERVOPACK monitoring function.

If SigmaWin+ or the utility function Fn01E (SERVOPACK and servomotor ID Display) is used to monitor the serial number, "\*\*\*\*\*\*\*\*\* will be displayed.

#### ■ Precautions

- If the scale parameters have not been written in the linear scale, A.CA0 (Encoder Parameter Error) will occur when the power is turned ON. Contact the linear scale manufacturer.
- If the motor parameters have not been written in the linear scale A.CA0 (Encoder Parameter Error) will not occur when the power is turned ON. Monitor the motor data using the monitoring function to see if the motor parameters are saved in the linear scale. If they are not saved, write the motor parameters and then turn the power OFF and then ON again to monitor the servomotor data.

If the motor parameters have not been written, the following alarms will occur when the power is turned ON:

 $A.040 \ (Parameter \ Setting \ Error \ 1), \ A.041 \ (Encoder \ Output \ Pulse \ Setting \ Error)$ 

A.050 (Combination Error), A.051 (Unsupported Device Alarm)

A.550 (Maximum Speed Setting Error), A.710 (Overload: High Load)

A.720 (Overload: Low Load), A.C90 (Encoder Communications Error)

## ■ How to Monitor the Motor Data Using the Digital Operator

• When the motor parameters have already been written

| Step | Display after operation   | Keys     | Operation  |
|------|---|----------|--|
| 1    | A. 550 — FUNCTION—<br>Fn01B: Vibl_vllmit<br>Fn01E: SvMotOp ID<br>Fn020: S—Orig Set<br>Fn080: Pole Detect  | MODE/SET | Press the Key to view the main menu of Utility Function.  Press the A or V Key to select Fn01E.  |
| 2    | A. 550 — S v & Mot I D — D r i v e r SGDV—2R8A15A D0039C546610020 07. 04 200V, 400W  SERVOPACK model  | DATA     | Press the DATA Key. The SERVOPACK model being used will be displayed.  |
| 3    | A.550 — S v & M o t I D — M o t o r S G L G W — DDDDDD S S G L G W — S G L G W — S G L G W — S G L G W — S G L G W — Connected servomotor model | DATA     | Press the DATA Key again. The connected servomotor model will be displayed. Note: If the linear scale data is not saved in the SERVOPACK, nothing will be displayed under Motor. |
| 4    | A. 5 5 0 −S v & M o t I D − E n c o d e r    JZDP-■□□□□-△△△   * * * * * * * * * 0 7. 0 4 0 9 b i t − A B S    Connected linear scale model      | DATA     | Press the Key again. The linear scale model will be displayed. Note: If the linear scale data is not saved in the SERVOPACK, nothing will be displayed under Encoder.            |

#### 5.3.1 Setting and Checking the Linear Scale Pitch

#### • When the motor parameters have not yet been written

| Proce-<br>dure | Display after operation  | Keys     | Operation  |
|----------------|--|----------|--|
| 1              | A.550 -FUNCTION-<br>Fn01C: Vibl_vllmit<br>Fn01E: SvMotOp ID<br>Fn020: S-Orig Set<br>Fn080: Pole Detect                               | MODE/SET | Press the Key to view the main menu of Utility Function.  Press the A or V Key to select Fn01E.  |
| 2              | A.550 — S v & M o t I D — D r i v e r SGDV — 2 R 8 A 0 1 A J D 0 0 3 9 C 5 4 6 6 1 0 0 2 0 0 7. 0 4 2 0 0 V, 4 0 0 W SERVOPACK model | DATA     | Press the DATA Key. The SERVOPACK model being used will be displayed.  |
| 3              | A. 550 — S v & M o t I D — M o t o r V V V V Connected servomotor model  | DATA     | Press the Key again. The connected servomotor model will be displayed. Note: If the linear scale data is not saved in the SERVO-PACK, nothing will be displayed under Motor. |
| 4              | A. 550 — S v & M o t I D — E n c o d e r  JZDP—■□□□□  *********  07. 04 09 b i t — A B S  Connected linear scale model               | DATA     | Press the DATA Key again. The linear scale model will be displayed. Note: If the linear scale data is not saved in the SERVO-PACK, nothing will be displayed under Encoder.  |

#### • When Using SigmaWin+

Start SigmaWin+. Click *Monitor* in the main menu and then click *Product Information*.

Note: The linear scale pitch can be checked by using the monitor mode parameters Un084 (Linear Scale Pitch) and Un085 (Linear Scale Pitch Index).

#### Example

```
When Un084 = 800, and Un085 = 6
Linear scale pitch = Un084 \times 10<sup>Un085</sup> [pm] = 800 \times 10<sup>6</sup> [pm] = 800 [\mum]
```

#### **5.3.2** Hall Sensor Selection

(1) Linear Servomotor with Hall Sensor

For a linear servomotor with hall sensor, use the factory setting: Pn080.0 = 0

#### (2) Linear Servomotor without Hall Sensor

For a linear servomotor without hall sensor, select *Disables selection* for the parameter Pn080.0. The factory setting is Pn080.0 = 0 (Enables selection), so change the setting to Pn080.0 = 1 (Disables selection). After having changed the setting, turn OFF the power supply and then ON to enable new setting.

| Para    | ameter | Meaning                             | When Enabled  |
|---------|--------|-------------------------------------|---------------|
| Pn080   | n.□□□0 | Enables selection [factory setting] | After restart |
| 1 11000 | n.□□□1 | Disables selection                  | Arter restart |

When Pn080.0 = 0 is set without connecting a hall sensor, the alarm A.C21 (Hall Sensor Error) will occur when the power supply is turned ON.

#### **5.3.3** Motor Phase Selection

Check the following feedback signals to the SERVOPACK, and set the motor phase sequence using the parameter Pn080.1.

- Check whether the signals from the linear scale are correctly received.
- Check whether the forward direction and linear scale count direction are the same.



- Before checking the feedback signals, be sure to set Pn000.0 to 0 (linear scale counting-up (phase-A advance) direction as forward direction).
- Be sure to check the feedback signals before operating the linear servomotor. If the linear servomotor is operated without checking the feedback signals, the linear servomotor may not run, or overrun may occur.

### ■ Checking the Signals from the Linear Scale


- Turn ON the control power to the SERVOPACK and set to servo OFF status.
- **2.** Displays the monitor mode parameter Un00D (Feedback Pulse Counter) on the panel operator or digital operator.
- **3.** Move the linear servomotor from end to end of the stroke by hand, and check whether the correct number of feedback pulses is returned.

#### 5.3.3 Motor Phase Selection

#### <Example>

Using a linear scale with a scale pitch of  $20~\mu m$ , if the linear servomotor is moved only 1 cm by hand in the linear scale's count direction, the number of feedback pulses will be as follows:

 $1 \text{ cm/} (20 \text{ } \mu\text{m}/256) = 128,000 \text{ pulses}$ 



When the linear servomotor is moved by hand to the side along the cable and the value of Un00D is 128000, it is confirmed that the SERVOPACK received the signal correctly.


Note: The actual monitor display will deviate by the error in movement distance only, so a value that is close to the above value is acceptable.

#### Note:

- When the Value of the Un00D is incorrect
   If the Un00D value is not displayed correctly, the following conditions may be present.
   Check the conditions and take appropriate countermeasures.
- The scale pitch of the linear scale does not match.
   If the scale pitch set in Pn282 is different from the actual scale pitch, the assumed number of feedback pulses will not be returned. Check the specifications of the linear scale.
- The linear scale has not been adjusted.
   If the linear scale is not adjusted, the linear scale's output signal level will drop and the count will not be correct. Check that the linear scale is correctly adjusted. For details, contact the scale's manufacturer.
- The wiring between the linear scale and serial converter unit is not correct.
   If the wiring is not correct, a normal count will not be performed. Rewire the devices correctly.

# ■ Checking the Concurrence between the Linear Scale Count Direction and the Linear Servomotor Forward Direction

Next, move the moving coil by hand in the direction of the side along the cable, and check that the Un00D monitor is counting up.



When the linear servomotor is moved by hand to the side along the cable, if the value of Un00D is a countup value, confirmation is completed.

Note: When the Value of the Un00D is counted down

When the value of the Un00D is a counted down, set the parameter Pn080.1 = 1 (Sets phase B lead as phase sequence of U, V, W). Enable the setting by turning OFF the power and then ON again.

#### ■ Related Parameter

| Para  | meter  | Meaning  | When Enabled  |
|-------|--------|--|---------------|
| Pn080 | n.□□0□ | Sets phase A lead as phase sequence of U, V, W (factory setting) | After restart |
|       | n.□□1□ | Sets phase B lead as phase sequence of U, V, W                   |               |

### **5.3.4** Setting the Overtravel Signals

Polarity detection cannot start in overtravel state.

When using the overtravel function, connect the signal wires and use in base block status. When not using the overtravel function, set the parameters Pn50A.3 to 8 (Forward run allowed) and Pn50B.0 to 8 (Reverse run allowed). The setting validation is required to enable the settings.

### **5.3.5** Setting the Force Limits

To prevent danger during setup of the linear servomotor, the factory settings for the forward force limit (Pn483) and reverse force limit (Pn484) parameters are set to a small value (factory setting: 30%).

If the force limits are set after the steps described in 5.3.1 Setting and Checking the Linear Scale Pitch and 5.3.2 Hall Sensor Selection, overrun will not occur. Increase the value in the parameters up to the required force. Set the value to the maximum value if no particular restricting conditions apply.

|       | Forward Force Limit |              | Speed Position Force |              |  |
|-------|---------------------|--------------|----------------------|--------------|--|
| Pn483 | Setting Range       | Setting Unit | Factory Setting      | When enabled |  |
|       | 0 to 800            | 1%           | 30                   | Immediately  |  |
|       | Reverse Force Limit |              | Speed Position Force |              |  |
| Pn484 | Setting Range       | Setting Unit | Factory Setting      | When enabled |  |
|       | 0 to 800%           | 1%           | 30                   | Immediately  |  |

Note: If the force limit is set too high, polarity detection may not operate normally

### **5.4** Execution of Origin Setting (Fn020)

When using an absolute linear scale model ST78□A□ manufactured by Mitutoyo Corporation, execute the origin setting.

### **⚠** CAUTION

- Be sure to set the linear servomotor to the servo OFF state before executing the origin setting function.
- Make sure that the parameter Fn010 (Write Prohibited Setting) is not set to prohibit writing.
- After execution of the origin setting, the servo ready (/S-RDY) signal will become inactive and the servo will be unable to draw power since the system position data has been changed. Always turn the power supply OFF and then ON again after execution of origin setting.
- After execution of the origin setting, the motor phase data in the SERVOPACK will be lost. Execute the polarity detection (Fn080) and save the motor phase data in the SERVOPACK.
- Origin setting using the utility function is required only for the initial setup.
  If the position data is carelessly changed, the origin of the linear scale will be changed
  and the machine may move in unexpected ways, resulting in damage to the product or
  injury.

The origin setting can be executed by using either the digital operator or panel operator.

### ■ Using the Panel Operator

| Step | Display after operation  | Keys     | Operation   |
|------|--|----------|---|
| 1    | BB -FUNCTION-<br>Fn01F:FBOpMot ID<br>Fn020:S-Orig Set<br>Fn030:Soft Reset<br>Fn080:Pole Detect | MODE/SET | Press the Key to view the main menu of Utility., and select Fn020 using the A or V Key. |
| 2    | BB Scale Origin Set ORGSET1  | DATA     | Press the DATA Key. The screen will change to the Fn020 (Origin Setting) main window.   |
| 3    | BB Scale Origin Set ORGSET5  | or V     | Press the   |

| Step | Display after operation | Keys | Operation   |
|------|-------------------------|------|---|
| 4    | BB<br>Scal Origin Set   | DATA | Press the DATA Key to start the origin setting. During origin setting, "Scale Origin Set" will be displayed blinking. When the origin setting is completed, the display stops blinking, and the status will be changed as BB→DONE→A.941*. |
| 5    |                         |      | To enable the setting, turn OFF the power to the SERVOPACK and then ON again.   |

- \* With SGDV SERVOPACK that support MECHATROLINK-III or MECHATROLINK-III, "A.941" will not be shown, and "BB" will be displayed instead.
- Using the Panel Operator

| Step | Display after operation | Keys                | Operation   |
|------|-------------------------|---------------------|---|
| 1    | F-000                   | MODE/SET A DATA/    | Press the MODE/SET Key to select the Utility Function mode.   |
| 2    | Fn020                   | MODE/SET A DATA/    | Press the UP or DOWN Key to select Fn020.   |
| 3    | 05821                   | MODE/SET ▲ DATA/◀   | Press the DATA/SHIFT Key for approximately one second. The display shown on the left will appear.   |
| 4    | 05845                   | MODE/SET ▲ ▼ DATA/◀ | Keep pressing the UP Key until 0SET5 appears. Note: If the correct key is not properly pressed, No_oP will be displayed blinking and the display will return to that of step 1. |
| 5    | (Displayed blinking)    | MODE/SET ▲ DATA/◀   | Press the MODE/SET Key to set the scale origin. When the origin is set, donE is displayed blinking for approximately one second.  |
| 6    |                         | One second after    | The display donE is changed to OSET5.   |

| Step | Display after operation  | Keys             | Operation  |
|------|--|------------------|--|
| 7    | F-020  | MODE/SET A DATA/ | Press the DATA/SHIFT Key for approximately one second. The display will return to Fn020. |
| 8    | Turn OFF the power to the SERVOPACK and then ON again to enable the setting. |                  |  |

### **5.5** Polarity Detection

When using a linear servomotor without hall sensor, execute the polarity detection.


Make sure that the following conditions are satisfied when executing the polarity detection.

- There will be no danger around the linear servomotor when the linear servomotor moves approximately 10 mm.
  - (The linear servomotor may move approximately 5 cm in the case the polarity detection fails. The distance the linear servomotor moves in such case may differ depending on many factors.)
- The scale pitch is within 100  $\mu m$ . (within 40  $\mu m$  is recommended when using an incremental linear scale.)
- Minimum unequal external force on the linear servomotor (5% of the rated force maximum is recommended.)
- The mass ratio is 50 times greater or less.
- On a horizontal axis.
- Friction on the guide is a few percentages of the rated force (air slide not used).



IMPORTANT

- The linear servomotor is turned ON during polarity detection, so take measures to avoid electric shock. The linear servomotor will make large movements during detection, so take the machine's range of motion into consideration and do not stand near the any moving parts.
- Polarity detection depends on many factors, such as mass ratio, friction, and cable tension. If any error occurs because of one of these factors, polarity detection may failed.



#### 5.5.1 When Using an Incremental Linear Scale

### **5.5.1** When Using an Incremental Linear Scale

### (1) Executing the Utility Function: Polarity Detection (Fn080)

To adjust the polarity of linear servomotor, use the following utility function: Polarity Detection (Fn080).

The following items must be confirmed before executing the polarity detection.

- The parameter Fn010 (Writing Prohibited Setting) is not set to prohibit writing.
- Linear servomotor is turned OFF.

The polarity detection can be executed by using either the digital operator or panel operator.

### ■ Using the Digital Operator

| Step | Display after operation  | Keys        | Operation   |
|------|--|-------------|---|
| 1    | BB -FUNCTION-<br>Fn030:Soft Reset<br>Fn080:Pole Detect<br>Fn200:TuneLvI Set<br>Fn201:AAT | MODE/SET    | Press the Key to view the main menu of Utility Function.  Press the A or V Key to select FN080.   |
| 2    | BB  Magnetic Pole  Detect  Level=40  | A V  ADATA  | Press the DATA Key.  The Fn080 (Polarity Detection) execution window will open.  To adjust the level:  Press the or Key to move the cursor from/to the digit.  Press the or V Key to change the value of each digit.  |
| 3    | BB  Magnetic Pole Detect  Start:[JOGSVON] Return:[SET]                                   | DATA        | Press the NATA Key. The display shown on the left will appear.  |
| 4    | P DET Magnetic Pole Adjustment Return:[SET]  | JOG<br>SVON | Press the (soo) Key. The linear servomotor will be in servo ON status and the polarity detection will start. During the polarity detection, "Magnetic Pole Adjustment" is displayed blinking. When the polarity detection is complete, the linear servomotor will be in servo OFF status. |

(cont'd)

| Step | Display after operation  | Keys     | Operation   |
|------|--|----------|---|
| 5    | BB  Magnetic Pole  Detect  Return:[SET]  |          | When the polarity detection is complete, the display shown on the left will appear. |
| 6    | BB -FUNCTION-<br>Fn030:Soft Reset<br>Fn080:Pole Detect<br>Fn200:TuneLvI Set<br>Fn201:AAT | MODE/SET | Press the Key. The display will return to the Utility Function main menu.           |

## ■ Using the Panel Operator

| Step | Display after operation | Keys                | Operation  |
|------|-------------------------|---------------------|--|
| 1    | F-000                   | MODE/SET A DATA     | Press the MODE/SET Key to select the Utility Function mode.  |
| 2    | F-080                   | MODE/SET ▲ DATA/◀   | Press the UP or DOWN Key to select Fn080.  |
| 3    | FPBEL                   | MODE/SET ▲ ▼ DATA/◀ | Press the DATA/SHIFT Key for approximately one second. The display shown on the left will appear.  |
| 4    | PUEL.                   | MODE/SET ▲ DATA/◀   | Press the MODE/SET Key to start the polarity detection.  |
| 5    | FPBEL                   |                     | When the polarity detection is complete, the display shown on the left will appear. The linear servomotor will be in the servo OFF status. |
| 6    | F-080                   | MODE/SET A DATA/    | Press the DATA/SHIFT Key for approximately one second. The display will return to Fn080.   |

### 5.5.2 When Using an Absolute Linear Scale

### **5.5.2** When Using an Absolute Linear Scale

### (1) Executing the Utility Function: Polarity Detection (Fn080)

To adjust the polarity of linear servomotor, use the following utility function: Polarity Detection (Fn080). Because this function is used as part of the initial setup, it is usually not necessary to execute this function a second time.

### **∧** CAUTION

 If the SERVOPACK, the absolute linear scale, or the linear servomotor is replaced, the polarity detection function must be executed again.
 Failure to observe this caution may result in the linear servomotor moving in an unpredictable manner.

The following items must be confirmed before executing the polarity detection.

- The parameter Fn010 (Writing Prohibited Setting) is not set to prohibit writing.
- · Linear servomotor is turned OFF.

The polarity detection can be executed by using either the digital operator or panel operator.

## ■ Using the Digital Operator

| Step | Display after operation  | Keys        | Operation  |
|------|--|-------------|--|
| 1    | BB -FUNCTION-<br>Fn030:Soft Reset<br>Fn080:Pole Detect<br>Fn200:TuneLvI Set<br>Fn201:AAT | MODE/SET    | Press the Key to view the main menu of Utility Function.  Press the A or V Key to select Fn080.  |
| 2    | BB Magnetic Pole Detect Level=40   | A V  ADATA  | Press the And Key. The Fn080 (Polarity Detection) execution window will open. To adjust the level, Press the or Key to move the cursor from/to the digit. Press the A or Key to change the value of each digit.  |
| 3    | BB  Magnetic Pole  Detect  Start:[JOGSVON]  Return:[SET]                                 | DATA        | Press the DATA Key. The display shown on the left will appear.   |
| 4    | P DET  Magnetic Pole  Adjustment  Return:[SET]   | JOG<br>SVON | Press the (\$\sqrt{900}\$) Key. The linear servomotor will be in servo ON status and the polarity detection will start. During the polarity detection, "Magnetic Pole Adjustment" is displayed blinking. When the polarity detection is complete, the linear servomotor will be in servo OFF status. |
| 5    | BB Magnetic Pole Detect Return:[SET]   |             | When the polarity detection is complete, the display shown on the left will appear.  |
| 6    | BB -FUNCTION-<br>Fn030:Soft Reset<br>Fn080:Pole Detect<br>Fn200:TuneLvI Set<br>Fn201:AAT | MODE/SET    | Press the Key. The display will return to the utility function main menu.  |
|      |  |             |  |

### 5.5.2 When Using an Absolute Linear Scale

### ■ Using the Panel Operator

| Step | Display after operation  | Keys                | Operation  |
|------|--|---------------------|--|
| 1    | F-000  | MODE/SET ▲ DATA/◀   | Press the MODE/SET Key to select the Utility Function mode.  |
| 2    | F-080  | MODE/SET ▲ ▼ DATA/◀ | Press the UP or DOWN Key to select Fn080.  |
| 3    | FPBEL  | MODE/SET ▲ DATA/◀   | Press the DATA/SHIFT Key for approximately one second. The display shown on the left will appear.                                      |
| 4    | PUEL.  | MODE/SET A DATA/    | Press the MODE/SET Key to start the polarity detection.  |
| 5    | FPBEL  |                     | When the polarity detection is complete, the display shown on the left will appear. The linear servomotor will be in servo OFF status. |
| 6    | F-080  | MODE/SET ▲ DATA/◀   | Press the DATA/SHIFT for approximately one second. The display will return to Fn080.   |
| 7    | Turn OFF the power to the SERVOPACk and then ON again to enable the setting. |                     |  |

### **5.5.3** Troubleshooting for Polarity Detection Errors

Refer to the following table for troubleshooting if polarity detection is not completed normally.

| No. | Problem   | Cause  | Countermeasure   |
|-----|---|--|--|
|     |   | Parameter settings are incorrect.                        | The settings for linear scale pitch (Pn282) and motor phase selection (Pn080.1) may not be appropriate for the device. Check the linear scale specifications and feedback signal conditions.   |
|     |   | Noise is present in the scale signal.                    | When the detection reference is repeatedly output several times in the same direction, noise may occur in the scale signal, resulting in malfunction. Check that the FG of the serial converter unit and linear servomotor is connected to FG of the SERVOPACK, and that FG of the SERVOPACK is connected to the power supply FG. Also check that the encoder cable is securely sealed.                      |
| 1   | Polarity detection error (A.C50)                            | The moving coil is being subjected to an external force. | If the moving coil is subjected to a gravity or/and an external force such as cable tension, and the speed feedback is not 0 regardless of a 0 detection reference, polarity detection will be poor.  Reduce the external force and make the speed feedback 0.  If the external force can not be reduced, increase the value of the changes in the sequence input signal allocation for each signal (Pn481). |
|     |   | The linear scale resolution is rough.                    | When the linear scale pitch is $100~\mu m$ min., the SER-VOPACK cannot detect correct speed feedback. Use a linear scale with good scale pitch precision (within $40~\mu m$ is recommended). Alternatively, increase the value of the polarity detection reference speed (Pn485). The range of linear servomotor movement at polarity detection, however, will increase.                                     |
| 2   | Overtravel<br>detection at<br>polarity detection<br>(A.C51) | The OT signal was detected during polarity detection     | The alarm A.C51 occurs when the OT signal is detected during polarity detection. Before executing the polarity detection, place the motor to the position where the OT signal is not detected.   |

### 5.5.3 Troubleshooting for Polarity Detection Errors

|     |   |   | (cont d)   |
|-----|---|---|--|
| No. | Problem                                     | Cause   | Countermeasure   |
|     |   | <pre><analog model="" pulse=""> • Polarity detection was not yet complete. • The /PDET signal was not input.  <m-ii command<="" m-iii="" model="" pre=""></m-ii></analog></pre>   | Input the /PDET signal.  When using an absolute linear scale, set Pn587.0 to 1 to execute polarity detection.  |
| 3   | Polarity detection uncompleted (A.C52)      | Option Attachable<br>Type> The servo has<br>been turned ON<br>under the<br>following<br>circumstances.  |  |
|     |   | An absolute linear scale is being used.     The polarity detection selection for the absolute linear scale was set to not execute. (Pn587.0=0)     Polarity was not yet detected. |  |
| 4   | Out of range for polarity detection (A.C53) | The movement distance during detection exceeds the range set for Pn48E.   | An alarm occurs when the motor movement distance during detection becomes out of the range set for Pn48E. If the command distance has not been changed from the factory set value, the motor might have been moved for some reason. Check for the cause and take a proper measure. |
| 5   | Polarity detection<br>error 2 (A.C54)       | An external force was applied to the linear servomotor.   | Increase the value of the polarity detection confirmation force reference (Pn495).  Increase the value of the polarity detection allowable error range (Pn498). (Note that increasing the allowable error will also increase the servomotor temperature.)                          |

#### **Related Parameters** 5.5.4

| Pn482 Setting Range   Setting Unit   Factory Setting   When enabled   |       | Changes the seque                         | ence input signal al | location for    | Speed Position Force |
|---|-------|---|----------------------|-----------------|----------------------|
| Polarity Detection Speed Loop Integral Time Constant  Setting Range Setting Unit Setting Range Polarity Detection Reference Speed Speed Position Force  Polarity Detection Reference Speed Speed Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  15 to 51200  1 mm/s  Setting Range Setting Unit Factory Setting When enabled  1 to 1000  1 mm/s  20 Immediately  Polarity Detection Reference Accel/Decel Time Speed Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  1 to 1000  1 ms 25 Immediately  Polarity Detection Reference Constant Speed Time Speed Position Force  Polarity Detection Reference Waiting Time Speed Fosition Force  Polarity Detection Reference Waiting Time Speed Fosition Force  Polarity Detection Reference Waiting Time Speed Fosition Force  Polarity Detection Range Setting Unit Factory Setting When enabled  1 to 65535  1 mm 100 Immediately  Polarity Detection Load Level Speed Fosition Force  Polarity Detection Load Level Speed Fosition Force  Polarity Detection Confirmation Force Reference Speed Fosition Force | Pn481 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Setting Range   Setting Unit   Factory Setting   When enabled   |       | 10 to 20000                               | 0.1 Hz               | 400             | Immediately          |
| Setting Range   Setting Unit   Factory Setting   When enabled   |       |   | Speed Loop Integra   | al Time         | Speed Position Force |
| Pn485 Pn486 Polarity Detection Reference Speed Setting Range Setting Unit Factory Setting When enabled 0 to 100   | Pn482 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn485   Setting Range   Setting Unit   Factory Setting   When enabled   |       | 15 to 51200                               | 0.01 ms              | 3000            | Immediately          |
| Pn486 Polarity Detection Reference Accel/Decel Time Speed Position Force  Polarity Detection Reference Constant Speed Position Force  Polarity Detection Reference Constant Speed Position Force  Polarity Detection Reference Constant Speed Setting Unit Factory Setting When enabled Position Force  Polarity Detection Reference Constant Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Polarity Detection Reference Waiting Time Speed Position Force  Polarity Detection Reference Waiting Time Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Polarity Detection Range Speed Position Force  Polarity Detection Range Speed Position Force  Polarity Detection Load Level Speed Position Force  Polarity Detection Load Level Speed Position Force  Polarity Detection Load Level Speed Position Force  Polarity Detection Confirmation Force Reference Speed Position Force  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Oto 2000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Oto 2000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Oto 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   |       | Polarity Detection                        | Reference Speed      |                 | Speed Position Force |
| Polarity Detection Reference Accel/Decel Time  Setting Range Setting Unit Factory Setting When enabled  0 to 100 1 ms 25 Immediately  Polarity Detection Reference Constant Speed Time  Setting Range Setting Unit Factory Setting When enabled  0 to 300 1 ms 0 Immediately  Polarity Detection Reference Waiting Time Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  Setting Range Setting Unit Factory Setting When enabled  50 to 500 1 ms 100 Immediately  Polarity Detection Range Setting Unit Factory Setting When enabled  Setting Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Pn490 Setting Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  1 to 20000 1 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  1 to 200 1 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   | Pn485 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn486   Setting Range   Setting Unit   Factory Setting   When enabled   |       | 0 to 100                                  | 1 mm/s               | 20              | Immediately          |
| Pn487 Pn487 Polarity Detection Reference Constant Speed Time Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Reference Waiting Time Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Reference Waiting Time Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Load Level Speed Position Force  Pn490 Polarity Detection Confirmation Force Reference Speed Position Force  Pn495 Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled Immediately  Polarity Detection Allowable Error Range Speed Position Force   |       | Polarity Detection                        | Reference Accel/De   | ecel Time       | Speed Position Force |
| Polarity Detection Reference Constant Speed   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    0 to 300   1 ms   0   Immediately    Polarity Detection Reference Waiting Time   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    50 to 500   1 ms   100   Immediately    Polarity Detection Range   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    1 to 65535   1 mm   10   Immediately    Polarity Detection Load Level   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    1 to 20000   1%   100   Immediately    Polarity Detection Confirmation Force Reference   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    1 to 2000   1%   100   Immediately    Polarity Detection Confirmation Force Reference   Speed   Position   Force    Setting Range   Setting Unit   Factory Setting   When enabled    1 to 200   1%   100   Immediately    Polarity Detection Allowable Error Range   Speed   Position   Force   | Pn486 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Time    Setting Range   Setting Unit   Factory Setting   When enabled   |       | 0 to 100                                  | 1 ms                 | 25              | Immediately          |
| Setting Range   Setting Unit   Factory Setting   When enabled   |       |   |                      |                 | Speed Position Force |
| Pn488 Polarity Detection Reference Waiting Time Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 50 to 500 1 ms 100 Immediately  Polarity Detection Range Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 10 to 2000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 10 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force  | Pn487 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn488       Setting Range       Setting Unit       Factory Setting       When enabled         50 to 500       1 ms       100       Immediately         Polarity Detection Range       Speed Position Force         Setting Range       Setting Unit       Factory Setting       When enabled         Pn490         Setting Range       Setting Unit       Factory Setting       When enabled         O to 20000       1%       100       Immediately         Pn495         Setting Range       Setting Unit       Factory Setting       When enabled         O to 2000       1%       100       Immediately         Polarity Detection Confirmation Force Reference       Speed Position Force         Speed Position Force         Polarity Detection Allowable Error Range  |       | 0 to 300                                  | 1 ms                 | 0               | Immediately          |
| Pn48E Polarity Detection Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force  |       | Polarity Detection Reference Waiting Time |                      |                 | Speed Position Force |
| Pn48E Setting Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 2000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   | Pn488 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn48E Setting Range Setting Unit Factory Setting When enabled  1 to 65535 1 mm 10 Immediately  Polarity Detection Load Level Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force  |       | 50 to 500                                 | 1 ms                 | 100             | Immediately          |
| Pn490 Pn490 Pn490 Polarity Detection Load Level Setting Range Setting Unit Office Setting Range Setting Unit Setting Range Setting Unit Setting Range Setting Unit Factory Setting When enabled Office Setting Range Polarity Detection Confirmation Force Reference Setting Range Setting Unit Factory Setting When enabled Office Setting Range Setting Unit Factory Setting When enabled Office Setting Range Setting Unit Factory Setting When enabled Office Setting Range Setting Unit Factory Setting Setting When enabled Office Setting Range Setting Unit Factory Setting Setting When enabled Office Setting Range Setting Unit Factory Setting Setting Force Setting Range Setting Unit Factory Setting Setting Force   |       | Polarity Detection Range                  |                      |                 | Speed Position Force |
| Pn490 Pn490 Pn490 Polarity Detection Load Level Speed Position Force Setting Range Setting Unit Factory Setting When enabled  0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   | Pn48E | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn490 Setting Range Setting Unit Factory Setting When enabled  0 to 20000 1% 100 Immediately  Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   |       | 1 to 65535                                | 1 mm                 | 10              | Immediately          |
| Pn495 Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled 0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force  |       | Polarity Detection Load Level             |                      |                 | Speed Position Force |
| Pn495 Polarity Detection Confirmation Force Reference Speed Position Force  Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   | Pn490 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| Pn495 Setting Range Setting Unit Factory Setting When enabled  0 to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force   |       | 0 to 20000                                | 1%                   | 100             | Immediately          |
| O to 200 1% 100 Immediately  Polarity Detection Allowable Error Range Speed Position Force  |       | Polarity Detection                        | Confirmation Force   | Reference       | Speed Position Force |
| Polarity Detection Allowable Error Range Speed Position Force   | Pn495 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
|   |       | 0 to 200                                  | 1%                   | 100             | Immediately          |
| Pn498 Setting Range Setting Unit Factory Setting When enabled   |       | Polarity Detection                        | Allowable Error Rai  | nge             | Speed Position Force |
| Setting Transc Setting Sint Tactory Setting When chapter  | Pn498 | Setting Range                             | Setting Unit         | Factory Setting | When enabled         |
| 0 to 30 1° 10 Immediately   |       | 0 to 30                                   | 1°                   | 10              | Immediately          |

### **5.6** JOG Operation

After setting and checking the items described in the previous sections, conduct a JOG operation as follows.

The JOG operation is the function used to check the movement of the linear servomotor in speed control without connecting the SERVOPACK to the host controller.

### ♠ WARNING

• When turning ON the servo for the first time after installation and wiring, stand away from the linear servomotor as overrun may occur.

### **∧** CAUTION

 During a JOG operation, the overtravel function is disabled. So take the machine's range of motion into consideration.

Note: If possible, execute the JOG operation without connecting a load to the linear servomotor (no-load operation).

#### ■ Check Items Before Execution

Check the following items before executing the JOG operation.

- The parameter Fn010 (Writing Prohibited Setting) is not set to prohibit writing.
- The main circuit power supply is ON.
- No alarm is occurring.
- The HWBB function is disabled.
- The linear servomotor is in servo OFF status.
- The JOG speed is properly set considering the motion range of the machine to be connected to the linear servomotor.
   Set the JOG speed using the parameter Pn383.

| <b>D</b> 200 | JOG Speed     |        | Speed           | Classification |       |
|--------------|---------------|--------|-----------------|----------------|-------|
| Pn383        | Setting Range | Unit   | Factory Setting | When Enabled   |       |
|              | 0 to 10000    | 1 mm/s | 50              | Immediately    | Setup |

- **1.** Turn ON the control power and main circuit power supplies.
- **2.** Use the panel operator, digital operator, or SigmaWin+ to move the linear servomotor in JOG operation.
- **3.** Check that the linear servomotor properly moves from one end to the other end of the stroke.



The tuning-less function is by default set enabled. When the tuning-less function is enabled, the gain may be so increased to cause vibration during no-load operation. If vibration occurs, disable the tuning-less function by setting the parameter Pn170.0 to 0.

#### ■ When Noises from the Linear Servomotor Cause a Problem

Select the Speed Detection 2 by setting the parameter Pn009.2 (Speed Detection Method Selection) to 1. And, turn OFF the power to the SERVOPACK and then ON again to enable the setting. It will be effective for the scale with a relatively long scale pitch.

| Para  | ameter                                | Meaning   | When Enabled  | Classification |
|-------|---------------------------------------|---|---------------|----------------|
| Pn009 | n.□0□□                                | Selects the speed detection 1 [factory setting) | After restart | Tuning         |
|       | n.□1□□ Selects the speed detection 2. |   |               |                |

If noises still cause a problem after having changed the speed detection method, use the current gain level setting function to change the current gain level.

The current gain level setting function reduces noises by adjusting the parameter value for current control inside the SERVOPACK in accordance with the parameter value for the speed loop gain (Pn100). To change the parameter value for current control, the current gain level must be changed from 2000%, which is the default value of Pn13D to disable this function. This function is always disabled in force control mode (Pn000.1 = 2).

|       | Current Gain Le | vel  | Speed Position  |              | Classification |
|-------|-----------------|------|-----------------|--------------|----------------|
| Pn13D | Setting Range   | Unit | Factory Setting | When Enabled |                |
|       | 100 to 2000     | 1%   | 2000            | Immediately  | Tuning         |

Note: If the set value of Pn13D is decreased, the level of noise will be lowered, but the responsiveness of the SERVOPACK will also be degraded. Lower the current gain level to one at which SERVOPACK responsiveness can be secured.

After having checked the above items, increase the values for the force limit function (Pn483 and Pn484) up to the required force. Set the value to the maximum value 800% if no particular restricting conditions apply.

Setup is finished when all these checks have been completed.


#### Note:

- · Unsuccessful Trial Operations
  - An unsuccessful trial operation could be attributed to the following conditions. Check the conditions and take appropriate measures.
- The force reference is saturated because the load is too heavy, or the jog speed is too
  fast
  - Lower the jog speed or lighten the load.
- The linear servomotor is moving slightly and then stops.
   The linear servomotor and linear scale are not in agreement. Check the wiring, scale pitch setting, linear scale count, and whether the motor forward direction matches the scale count direction.
- Polarity detection is not being performed normally. Refer to 5.5 Polarity Detection to execute the polarity detection.

### **5.6.1** JOG Operation Using a Panel Operator

This section describes the procedure for executing a JOG operation using a panel operator.

The panel operator is located under the front cover of the SERVOPACK (analog pulse models only).



| Step | Display after operation | Keys              | Operation  |
|------|-------------------------|-------------------|--|
| 1    | ↑ Alternate display     |                   | Turn ON the power to the SERVOPACK. The forward run prohibited (P-OT) or reverse run prohibited (N-OT) message is displayed. When the JOG operation is executed, P-OT and N-OT are automatically disabled. |
| 2    | F-000                   | MODE/SET A DATA/  | Press the MODE/SET Key to select the utility function mode.  |
| 3    | F-002                   | MODE/SET A DATA/  | Press the UP or DOWN Key to select Fn002.  |
| 4    |                         | MODE/SET ▲ DATA/◀ | Press the DATA/SHIFT Key for approximately one second. The display shown on the left will appear.  |
| 5    |                         | MODE/SET A DATA/  | Press the MODE/SET Key. The linear servomotor will be in servo ON status.  |


### 5.6.1 JOG Operation Using a Panel Operator

| Step | Display after operation | Keys              | Operation (cont d)   |
|------|-------------------------|-------------------|--|
| 6    |                         | MODE/SET ▲ DATA/■ | Press the UP Key to move the linear servo- motor in the forward direction or press the DOWN Key to move it in reverse. The lin- ear servomotor will move at the speed set in the parameter Pn383 while the key is being pressed.  Forward direction  Reverse direction |
| 7    |                         | MODE/SET ■ DATA/◀ | Press the MODE/SET Key. The linear servomotor will be in servo OFF status. Note: The linear servomotor can be also in servo OFF status by pressing the DATA/SHIFT Key for approximately one second.  |
| 8    | F-002                   | MODE/SET ▲ DATA/◀ | Press the DATA/SHIFT Key for approximately one second. "Fn002" is displayed again.   |
| 9    | Alternate display       | MODE/SET A DATA/  | Press the MODE/SET Key to return to the initial display (step 1).  |

## **5.6.2** JOG Operation Using a Digital Operator

This section describes the procedure for executing a JOG operation using a digital operator.

Connect the digital operator to the SERVOPACK CN3 connector.



The digital operator can be connected or removed while the SERVOPACK power is ON.

The operation procedure is explained with the parameter Pn000.0 set to 0 (linear scale counting up direction as the forward direction).

| Step | Display after operation  | Keys     | Operation   |
|------|--|----------|---|
| 1    | BB -PRM/MON-<br>Un000=00000<br>Un002=00000<br>Un008=0000000000<br>Un00D=0000000000     |          | Turn ON the power to the SERVO-PACK. The initial window will appear, and then the parameter/monitor mode will appear. |
| 2    | BB -FUNCTION-<br>Fn000:Alm History<br>Fn002:JOG<br>Fn003:Z-Search<br>Fn004:Program JOG | MODE/SET | Press the Key to view the main menu of the Utility Function. Press the Key to select Fn002.                           |

### 5.6.2 JOG Operation Using a Digital Operator

| Step | Display after operation   | Keys        | Operation   |
|------|---|-------------|---|
| 3    | BB -JOG-<br>Pn383=00500<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000           | DATA        | Press the Key. The display will change to the execution display of Fn002.   |
| 4    | BB -JOG-<br>Pn383=00500<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000           | DATA        | Press the Key. The cursor will move to the setting data of JOG speed (Pn383).   |
| 5    | BB -JOG-<br>Pn383=01000<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000           | < ><br>A V  | Press the or Key, and the or Key to set the JOG speed to 1000 (mm/s).   |
| 6    | BB -JOG-<br>Pn383=01000<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000           | DATA        | Press the DATA Key.  The set value is input, and the cursor will move to the parameter number.  |
| 7    | RUN -JOG-<br>Pn383=01000<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000          | JOG<br>SVON | Press the (SON) Key.  "RUN" will be displayed in the status field, and the linear servomotor will be in servo ON status.  |
| 8    | RUN -JOG-<br>Pn38 <u>3</u> =01000<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000 | AV          | Press the   |
| 9    | BB -JOG-<br>Pn383=01000<br>Un000= 00000<br>Un002= 00000<br>Un00D=00000000           | JOG<br>SVON | After confirming that the linear servomotor moves correctly, press the Key.  "BB" will be displayed in the status field, and the linear servomotor will be in servo OFF status. |

| ~n | nt' | d١ |
|----|-----|----|
| 00 |     | u, |

| Step | Display after operation  | Keys     | Operation   |
|------|--|----------|---|
| 10   | BB -FUNCTION-<br>Fn000: Alm History<br>Fn002: JOG<br>Fn003: Z-Search<br>Fn004: Program JOG | MODE/SET | Press the Key.  The display will return to the main menu of the Utility Function. |
| 11   | BB -PRM/MON-<br>Un000=00000<br>Un002=00000<br>Un008=0000000000<br>Un00D=0000000000         | MODE/SET | Press the Key twice. The display will return to the initial window (step 1).      |

### ■ Alarm Display

An alarm is automatically displayed if a problem occurs for some reason. Check the alarm referring to the user's manual for the corresponding SERVOPACK or command option module (refer to  $\blacksquare$  Manuals Related to the  $\Sigma$ -V Series on page iv) and apply the appropriate measures.

| A. 710        | -ALARM-   |
|---------------|---|
| <u>A.</u> 710 | 0 0 0 0 1 2 0 7 1 9 6<br>0 0 0 0 0 0 3 2 6 5 1<br>0 0 0 0 0 0 0 9 0 4 3 |
| 1:720         | 00000032651   |
| 2:511         | 00000009043   |
| 3:            |   |

### ■ Error Display

The following messages will be displayed if a communications error occurs between the SERVOPACK and the digital operator due to a connection problem such as poor connector contact. Check the connections and turn the power ON again. If the problem still persists, the digital operator or SERVOPACK must be replaced.






### 5.6.3 JOG Operation Using SigmaWin+

### 5.6.3 JOG Operation Using SigmaWin+


This section describes the procedure for executing a JOG operation using SigmaWin+.

In the following example, test-run procedures are explained using the JOG operation window of Test Run on the main menu of SigmaWin+.

| Step | Operation  | Display  |
|------|--|--|
| 1    | Connect a computer. Use a connection cable to connect a SERVO-PACK to a computer which has SigmaWin+installed.  SERVOPACK  CN7  PC  Connection cable for personal computer  JZSP-CVS06-02-E  |  |
| 2    | • Start SigmaWin+ and open the main window.  (1) Turn ON the SERVOPACK. (2) Turn ON the computer.  (3) Double click the YE_Applications folder on the desktop.  (4) Double click the SigmaWin+ icon to display the SigmaWin+ startup screen. | YE_Applications  SigmaWin+ English Edition  SigmaWin+  SigmaWin+  Startup Screen |




#### 5.6.3 JOG Operation Using SigmaWin+



#### (cont'd) Step Operation Display · Set the JOG speed S JOG Operation AXIS#1 X The motor speed is set to 500 [mm/s]. Click JOG Speed Setting if you need to change it. Pn383 : JOG Speed 500 [mm/s] Edit Operation 4 OL Servo OFF Servo ON Superation AXIS#1 × JOG Speed Setting Servo ON Pn383: JOG Speed The display changes from Click 500 [mm/s] Edit Servo OFF to Servo ON and is lit in green. Operation 5 Servo ON

#### 5.6.3 JOG Operation Using SigmaWin+

(cont'd)




Refer to SigmaWin+ online manual for details. Follow the steps below to view the online manual.

<How to view the online manual>

- 1. Turn ON the computer.
- 2. Open the YE Applications folder.
- 3. Open the Manual folder.
- 4. Open SigmaWin+ English Edition Online Manual.

## **Revision History**

The revision dates and numbers of the revised manuals are given at the bottom of the back cover.



| Date of<br>Publication | Rev.<br>No. | WEB<br>Rev.<br>No. | Section                                 | Revised Content  |
|------------------------|-------------|--------------------|---|--|
| June 2012              | \$          | 0                  | All chapters                            | Revision: Model of SERVOPACK with MECHATROLINK-III communications (25A→25□)      |
|                        |             |                    | 4.5                                     | Addition: Description of safety function's jumper connector                      |
|                        |             |                    | Back cover                              | Revision: Address  |
| March 2011             | 2>          | 0                  | Front cover                             | Revision: Format   |
|                        | ~           |                    | 2.3.2 (3)                               | Addition: Linear scale made by Mitutoyo<br>ST788A□, ST789A□                      |
|                        |             |                    | 2.3.1,<br>2.3.2 (4),<br>3.5.2 (4)       | Revision: Sony Manufacturing Systems Corporation changed to Magnescale Co., Ltd. |
|                        |             |                    | 2.4.2, 2.5.1,<br>2.5.2, 3.2.1,<br>3.2.2 | Addition: Description of SGDV-□□□□□B SERVOPACKs                                  |
|                        |             |                    | Back cover                              | Revision: Address, format<br>Addition: Original instructions                     |
| January 2010           | 1>          | 0                  | All chapters                            | Completely revised   |
| September 2009         | <b>(</b> )  | 1                  | Preface                                 | Addition: Warranty   |
|                        |             |                    | Back cover                              | Revision: Address  |
| June 2007              |             | 0                  | _                                       | First edition  |

## AC Servo Drives $\Sigma$ -V Series USFR'S MANUAL Setup Linear Motor

#### IRUMA BUSINESS CENTER (SOLUTION CENTER)

480, Kamifujisawa, Iruma, Saitama 358-8555, Japan Phone 81-4-2962-5151 Fax 81-4-2962-6138

#### YASKAWA AMERICA, INC.

2121 Norman Drive South, Waukegan, IL 60085, U.S.A. Phone (800) YASKAWA (800-927-5292) or 1-847-887-7000 Fax 1-847-887-7310

#### YASKAWA ELÉTRICO DO BRASIL LTDA.

Avenida Fagundes Filho, 620 São Paulo-SP CEP 04304-000, Brazil

#### Phone 55-11-3585-1100 Fax 55-11-5581-8795

YASKAWA EUROPE GmbH

Hauptstraβe 185, Eschborn 65760, Germany Phone 49-6196-569-300 Fax 49-6196-569-398

#### YASKAWA ELECTRIC UK LTD.

1 Hunt Hill Orchardton Woods Cumbernauld, G68 9LF, United Kingdom

Phone 44-1236-735000 Fax 44-1236-458182

#### YASKAWA ELECTRIC KOREA CORPORATION

9F, Kyobo Securities Bldg. 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea Phone 82-2-784-7844 Fax 82-2-784-8495

#### YASKAWA ELECTRIC (SINGAPORE) PTE. LTD. 151 Lorong Chuan, #04-01, New Tech Park 556741, Singapore

Phone 65-6282-3003 Fax 65-6289-3003

#### YASKAWA ELECTRIC (SHANGHAI) CO., LTD.

12F, Carlton Bld., No.21 HuangHe Road, HuangPu District, Shanghai 200003, China

Phone 86-21-5385-2200 Fax 86-21-5385-3299

#### YASKAWA ELECTRIC (SHANGHAI) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1 East Chang An Ave., Dong Cheng District, Beijing 100738, China Phone 86-10-8518-4086 Fax 86-10-8518-4082

#### YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei 104, Taiwan Phone 886-2-2502-5003 Fax 886-2-2505-1280



YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply.

Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2007-2012 YASKAWA ELECTRIC CORPORATION. All rights reserved.

MANUAL NO. SIFP S800000 44D Published in Japan June 2012 07-6 11-12-5 Original instructions

